

Instruction Manual XENAX® Xvi 75V8

Translation of "Anleitung XENAX® Xvi 75V8"

Edition 2. November 2020

Compact Ethernet Servo Controller

EtherCAT®

PROFI
NET

EtherNet/IP™

CANopen®

ETHERNET
POWERLINK



Parameterization over Web browser

The integrated webserver allows a setup and parameterization over web browser.

After an automatic self-check, the connected LINAX® linear motor axis, the ELAX® electric slide or the ROTAX® rotary axis can instantly be set in motion by click on the Quick Start Button.

This XENAX® Xvi 75V8 is setting new standards in terms of intuitive handling.

General

The XENAX® Xvi 75V8 Ethernet servo controller controls all series of the LINAX® linear motor axes, the ELAX® electric slide product family and the ROTAX® rotary axis.

It is also possible to control servo motors series RAXx (ultra-compact rotary axes) and RT-xx (round table with hollow shaft).

Customary rotary AC/DC/EC servo motors for example from FAULHABER® or MAXON® can also be operated by the XENAX® Xvi 75V8.

The logic supply (24V DC) and the intermediate circuit voltage (24V – 75V DC) are separately connectable. This is how “Safety Torque Off” is possible as a standard.

Master-Slave function, Force Calibration (compensation of the cogging forces in iron core linear motors) and optional “Safety” functionalities such as SS1, SS2, or SLS are further features of this compact XENAX® Xvi 75V8 servo controller.

Alois Jenny
Jenny Science AG

Contents

1 Characteristics XENAX® Xvi 75V8	7
1.1 Electronics / Firmware	7
1.2 Performance / Options	7
1.3 Dimensions	8
2 Controllable Motor Types	9
2.1 Linear Motor Axes and Electric Slides	9
2.2 Servo Motors in our Product Line	9
2.3 Customary Servo Motors	10
3 Hardware and Installation	11
3.1 Environmental Conditions	11
3.2 Assembly and Installation	11
4 Functional Safety - TÜV certified	12
4.1 Hardware Requirements	12
4.2 Safety Standards	12
4.3 Basic Conditions	13
4.4 Technical Data Safety	14
4.5 Safety Functions	15
4.5.1 STO, Safe Torque Off	15
4.5.2 SS1, Safe Stop 1	15
4.5.3 SS2, Safe Stop 2	16
4.5.4 SLS, Safely Limited Speed	16
4.6 Functional Safety Parameterization in WebMotion®	17
4.6.1 Display Active Safety Parameters	17
4.6.2 Modification of Safety Parameters	17
5 UL	19
5.1 Ratings	19
6 Electrical Connections	20
6.1 Plug Arrangement	20
6.2 Plug Pin Configuration	20
6.2.1 RS232	20
6.2.2 Motor Plug 3 Phase	21
6.2.3 Logic and Power Supply	21
6.2.4 Encoder and Hall Signals	22
6.2.5 Definition of Rotating Direction for Servo Motors	22
6.2.6 OPTIO Pulse/Dir, Second Encoder Channel	23
6.2.7 PLC I/O	24
6.3 Internal I/O Circuit	25
6.4 Output Configuration	26
7 Configuration Motor Type Jenny Science / Motor customer specific	27
8 RS232 Serial Interface	28

8.1 Baud Rate RS232 XENAX®	28
9 ETHERNET TCP/IP Interface	28
9.1 Baud Rate Ethernet Gateway (XPort)	28
9.2 Default Setup Records Upgrade	30
9.3 Test IP Connection with >IPCONFIG	31
9.4 Test Connection with >PING	31
9.5 Change IP Address with "Device Installer"	31
9.6 Change Port Number with "Device Installer"	32
9.7 Close Port	33
10 ASCII Protocol	34
10.1 ASCII Protocol TCP/IP	35
10.2 Asynchronous Messages (Events)	35
11 Install JAVA Plugin	36
11.1 Applet Cache	37
11.2 Disable Java certificate Validation	37
12 WebMotion®	38
12.1 Start WebMotion®	38
12.1.1 Error „Upload XENAX Settings“	39
12.2 Quick Start (only with LINAX® and ELAX® linear motor axes)	40
12.3 Operation, Status Line	41
12.4 Move Axis by Click	42
12.4.1 Move Axis by Click for LINAX®/ELAX® Linear Motors	42
12.4.2 Move Axis by Click for ROTAX® Rotary Motor or Third Party Motors	44
12.5 Move Axis by Command Line	45
12.6 ASCII Command Set for XENAX®	45
12.6.1 Power / Reset	45
12.6.2 Basic Settings	46
12.6.3 Motor Settings	46
12.6.4 Controller Settings	46
12.6.5 Motion Settings	47
12.6.6 Reference LINAX® / ELAX®	48
12.6.7 Reference Gantry	48
12.6.8 Reference Rotary Motors	48
12.6.9 Move Commands	49
12.6.10 Index / Moves with I_Force (programmed movements)	49
12.6.11 Program / Application	50
12.6.12 Event	50
12.6.13 Input / Output	51
12.6.14 Limit Position ELAX®	52
12.6.15 Force Control	54
12.6.16 Correction Table	56
12.6.17 System Information	57
12.6.18 Bus Module Information	58

12.6.19 Error Handling	58
12.6.20 System Monitoring	58
12.7 Move Axis by Forceteq®	59
12.8 Move Axis Motion Diagram	59
12.9 Index	61
12.10 Drive I_Force	62
12.11 Sector I_Force	62
12.12 Program	63
12.12.1 Program commands	64
12.13 I/O Functions	67
12.13.1 Selection of Input Functions	68
12.13.2 Selection Output Functions	70
12.13.3 Operation with Additional Holding Brake	70
12.14 Profile (Velocity)	71
12.15 Captured Pos	72
12.16 State Controller	73
12.16.1 F Setting	76
12.17 Motor	79
12.17.1 Motors LINAX® and ELAX®	79
12.17.2 Motor ROTAX®	80
12.17.3 Third Party Motors	81
12.17.4 Position Overflow	82
12.18 Reference	83
12.18.1 Reference LINAX®	83
12.18.2 Reference ELAX®	83
12.18.3 Reference ROTAX® und Third Party Motors	85
12.18.4 Reference to Mechanical Stop	86
12.18.5 Correction Table for LINAX® / ELAX®	87
12.19 Basic Settings	90
12.20 Version	90
12.21 Update Firmware / WebMotion®	91
12.22 Save	92
12.23 Open	92
13 Master / Slave	93
13.1 Master/Slave Configuration	93
13.2 Programming example Pick&Place	94
13.3 Timing Master / Slave	94
14 Gantry Synchronized Mode	95
14.1 Activate Gantry Mode	95
14.2 ASCII Commands for Gantry Synchronized Mode	96
15 Force Process Forceteq®	97
15.1 Overview Forceteq® Functions	97
15.1.1 Force Calibration	98

15.1.2 Force Limitation	98
15.1.3 Force Monitoring	99
15.1.4 Force Control	100
15.2 Integration of Force Processes	101
15.2.1 XENAX® in Program	101
15.2.2 Over Command Set	103
15.2.3 Sector Offset for Touching Position	106
15.3 Application Example	107
15.3.1 Programming Force Process in XENAX®	108
15.3.2 Force Process with ASCII Commands	110
16 Operating Status on 7-Segment Display	111
17 Error Handling	112
17.1 Error Codes	112
17.2 Notes for Error 50	116
17.3 Notes for Error 89	117
17.4 Notes for Error 91	119
17.5 Arbitrary Display on 7-Segment	120
17.5.1 Defective adapter for logic supply	120
17.5.2 Defective Firmware	120
17.5.3 GAL contact problems, only with hardware <=2.0	121

1 Characteristics XENAX® Xvi 75V8

1.1 Electronics / Firmware

Description	Data
Interfaces	Ethernet, TCP/IP, http web server Puls/direction, Master Encoder, I/O I ² C Master/Slave, Start-up Key RS232
Bus, multi-axis operation	EtherCAT (CoE), DS402 Ethernet POWERLINK, DS402 CANopen, DS 402 PROFINET (PROFIdrive) EtherNet/IP, DS402 Ethernet Switch, TCP/IP
Operation Modes	Standard Servo (MODE 0) Multi axis operation (Master/Slave, Gantry) Electronic gear (MODE 1) Puls/Direction (MODE 2)
Safety Motion Unit SMU	Security module, 2-channel monitoring TÜV certified
	SIL 2 Safety Integrity Level 2 Cat 3 Category 3 PL d Performance Level d MTTFd 1733313 h
Status indication	7-Segment LED
Input digital	12 x 24V Pull down
Output digital	8 x 24V, 100mA Source or 400mA Sink
Input function	8 inputs to start a function or program
Output function	8 outputs to indicate a condition
Reference for rotary motors	free to define, incl. external sensor
Index	50 motion moves (accl. / speed / distance, position)
Profile	5 extended motion profiles with 7 profile segments each.
Number of application programs via input	15, Input 9-12 binary coded (MODE >=10)
Firmware update	Over TCP/IP, Flash-memory internal
Application and parameter update	Over TCP/IP, Flash-memory internal



1.2 Performance / Options


„LG“ logic supply	24VDC / max. 1.3 A
„PW“ power supply motor	12-75VDC
3- Phase Output frequency	0-599 Hz
Nominal current	0-8A
Peak current	18A
Continuous power / dissipation loss	Typical 48V / 3A / 150W / $\eta \approx 85\%$ / $P_v = 22W$
Temperature monitoring output stage	Shutdown at 80°C
Excess voltage – observation	> 85V
Under voltage – observation	< 10V
Ballast circuit	up to 80W
Fuse power	10AF
Motor temperature observation with LINAX®, ELAX® and ROTAX®, sensor in coils	Shutdown at 80°C

PLC Input	8 Inputs, 24V
PLC Input BCD	4 Inputs, 24V, binary coded for program selection
PLC Output	8 Outputs, 24V, Source 100mA, Sink 400mA, Source/Sink

Options

EtherCAT (CoE)	DS402, Beckhoff®, OMRON®, TRIO® MC
POWERLINK (CoP)	DS402, B&R®
CANopen	DS402
EtherNet/IP	DS402, Allen-Bradley
PROFINET (PROFIdrive)	SIMATIC, SIMOTION, SINUMERIK
SMU Safety Functions	STO Safe Torque Off SS1 Safe Stop 1 SS2 Safe Stop 2 SLS Safely-Limited Speed
Start-up Key	ID number for Master Slave and application memory
Force Processes	Enabled by default
Controllable Motor-Types	LINAX®, ELAX®, ROTAX® and third party motors enabled by default

1.3 Dimensions



Dirt resistance	IP 20
Weight	Standard 550g, with bus module 590g
Case	Coated
Ground plate	Aluminum sand-blasted


2 Controllable Motor Types

2.1 Linear Motor Axes and Electric Slides

LINAX® Linear Motors

3 phase synchronous linear motor with encoder RS422 A/A*, B/B* und Z/Z* and distance-coded reference marks.


Special feature:
Linear motor identification and temperature monitoring over I2C bus.



ELAX® Electric Slides with Linear Motor

ELAX® is the evolutionary step of the widespread pneumatic slides. The great accomplishment is the patented compact integration of the linear motor in the slider case, resulting in a force/volume ratio which has hitherto never been achieved.


Special feature:
Linear motor identification and temperature monitoring over I2C bus.



2.2 Servo Motors in our Product Line

ROTAX® Rotary motor axes

Specifically designed for fast and precise assembly and handling tasks. It can be equipped with standard gripping tools. The hollow shaft feedthrough for vacuum or compressed air enables a 360° rotation. The XENAX® servo controller identifies the ROTAX® rotary axis and configures the controller parameters automatically.



Rxhq = high torque



Rxvp = vacuum pressure

Lafert, RAxX, RTxx

AC-Servo motors with encoder A/A*, B/B* and Z/Z*
and hall sensors e.g.
AEG B28 D4 0,4Nm, 6000 U/min.
Optionally available with brakes for vertical
applications.

**2.3 Customary Servo Motors****Faulhaber®, Maxon®**

AC / DC / EC brushless servo motors with incremental
encoder RS422 A/A*, B/B* and Z/Z* and hall sensors,
as well as DC brush-type servo motors with
incremental encoder.

For brushless AC/EC servo motors there are hall
signals and incremental encoder necessary.



3 Hardware and Installation

3.1 Environmental Conditions


Storage and transport	No outdoor storage. Warehouses have to be well ventilated and dry. Temperature from -25°C up to +55°C
Temperature while operating	5°C -50°C environment, (above 40°C, nominal current reduced to 6A)
Humidity while operating	10-90% non-condensing
Air conditioning	No external air conditioning needed; integrated heat sink.

3.2 Assembly and Installation

Assembly with two screws on an electrically conductive rear wall e.g. the back wall of a switch cabinet.


For a series mounting the distance between the devices has to be at least 10mm and the distance to the floor has to be at least 40mm.

We recommend mounting the devices in vertical orientation with the 7-segment display at the top to ensure a good cooling air circulation.



When operating with a power supply motor above 60VDC, the XENAX® Servo controller must be mounted in an electrical control cabinet and the XENAX® Servo controller must be connected to protective earth using the shielding clamp (Art. No. 130.09.00) for motor cable.

When operating with a power supply motor below or equal 60VDC, a SELV/PELV power supply has to be used or XENAX® Servo controller must be connected to protective earth using the shielding clamp (Art. No. 130.09.00) for motor cable .



4 Functional Safety - TÜV certified

4.1 Hardware Requirements

In order to use the TÜV certified safety functions a XENAX® Servo controller equipped with an optional Safety Motion Unit (SMU) is needed.

The SMU module has to be ordered by the client with a separate article number.

XENAX® Servo controllers can only be upgraded to SMU at Jenny Science.

Upgrade is only possible with hardware V 4.0 or higher

SMU modules will only be supplied when mounted into a XENAX® Servo controller.



Functional Safety
SIL 2, PL d, Cat. 3

Legal Note:

In case of any modification or attempts of modification on the hardware by third parties, the TÜV certification is no longer guaranteed and Jenny Science declines all liability.

4.2 Safety Standards

EN 61508-1:2010 EN 61508-2:2010 EN 61508-3:2010 Functional safety of electrical/ electronic/programmable safety-related systems	SIL 2 Safety Integrity Level 2
EN ISO 13849-1:2015 Safety of machinery, Safety-related parts of control systems	Cat 3 Category 3 PL d Performance Level d
EN 61800-5-2:2017 Adjustable speed electrical power drive systems	Safety Functions: STO Safe Torque Off SS1 Safe Stop 1 SS2 Safe Stop 2 SLS Safely-Limited Speed

4.3 Basic Conditions

Motor Types	<p>Functional Safety with SMU can be used for all LINAX®, ELAX® and ROTAX® motor families, as well as rotary brushless motors with different A/B/Z encoder signals. Rotary brush type DC motors are not subject to the functional safety.</p> <p>Note1: For vertical mounted linear axis, weight compensation must be used for safety functions SS2 and SLS. The safety function SBC (Safe Break Control) is not available.</p> <p>Note2: Rotative motors operating suspended loads are excluded from SS2 and SLS safety functions.</p>
Commissioning	The configuration assessment has to be warranted by the client for each modification of the functional safety and its parameters through commissioning.
Period of use	The maximum period of use for operating with functional safety with SMU is 20 years.
Continuous operation	The XENAX® servo controller must be switched off at least once a year.
Wiring	The length of the connection cables must not exceed 30m per connection cable.

4.4 Technical Data Safety

Reaction time of the security inputs (until activation of a safety function)	< 2ms										
Probability of a dangerous failure per hour (PFH)	PFH = $51.7 \cdot 10^{-9}$ 1/h										
Activation of a safety function	Switching on two channel to 0V One-channel switched safety inputs lead to turn off of the power stage and requires a restart of the XENAX® servo controller.										
Level of safety inputs	>21.0V safety input inactive < 2.0V safety input active Voltage levels outside of these limits are prohibited.										
Hierarchy of safety functions	<table border="1"> <thead> <tr> <th>Hierarchy</th><th>Safety Functions</th></tr> </thead> <tbody> <tr> <td>4</td><td>STO Safe Torque Off</td></tr> <tr> <td>3</td><td>SS1 Safe Stop 1</td></tr> <tr> <td>2</td><td>SS2 Safe Stop 2</td></tr> <tr> <td>1</td><td>SLS Safely Limited Speed</td></tr> </tbody> </table> <p>Safety functions of higher hierarchy levels overdrive the ones below.</p>	Hierarchy	Safety Functions	4	STO Safe Torque Off	3	SS1 Safe Stop 1	2	SS2 Safe Stop 2	1	SLS Safely Limited Speed
Hierarchy	Safety Functions										
4	STO Safe Torque Off										
3	SS1 Safe Stop 1										
2	SS2 Safe Stop 2										
1	SLS Safely Limited Speed										

Deceleration ramps for SS1 Profile Position Mode and Cyclic Synchronized Position Mode (RT-Ethernet)		Trough parameter ED (Emergency Deceleration)
Deceleration ramps for SS2 Profile Position Mode Cyclic Synchronized Position Mode (RT-Ethernet)		With Parameter ED (Emergency Deceleration) Indicated by superior master controller
Deceleration ramps for SLS Profile Position Mode Cyclic Synchronized Position mode (RT-Ethernet)		After speed infringements through parameter ED (Emergency Deceleration) Indicated by superior master controller

4.5 Safety Functions


4.5.1 STO, Safe Torque Off

According IEC 61800-5-2

Immediate shut-down of the output stage.

Error 90 is generated if the power stage was switched on at the time of STO.

Parameter:
None




4.5.2 SS1, Safe Stop 1

Stop followed by shut-down of the output stage (Stop category 1)

Error 90 is generated if the power stage was switched on at the time of SS1.


Parameter:
Timeout Stop Δt_1 Standard 300ms



4.5.3 SS2, Safe Stop 2

Stop while remaining in stop position, axis remains under power, power stage active. Then observation of stop-position, status SOS (Safe Operating Stop). If exceeding the position limit, STO will be triggered. Shut-down of the output stage (stop category 2)


Parameter		
Timeout Stop	Δt_1	Standard 300ms
Position window	Δs	Standard ± 2500 Inc



4.5.4 SLS, Safely Limited Speed

Observation of a safe speed. If Safety Limited Speed (SLS) is exceeded, Safe Stop (SS2) while observing the position window. If position window is exceeded as well, then triggering STO, shut-down of the output stage. Adjustment of speed during SLS time out has to be specified by user.

Parameter:		
Timeout SLS	Δt_2	Standard 300ms
Safely Limited Speed	v_{max}	Standard $\pm 50'000$ Inc/s
Timeout Stop	Δt_1	Standard 300ms
Position window	Δs	Standard ± 2500 Inc



4.6 Functional Safety Parameterization in WebMotion®


4.6.1 Display Active Safety Parameters

The defined Safety Functions and parameters are shown in WebMotion® in the menu *application/io*. This safety information can only be read, not modified.

The parameters of the Safety Functions can be made visible by pressing „Safety Param“.

Please refer to chapter 12 WebMotion® for further explanations on WebMotion® interface.

If the XENAX® servo controller contains a Safety Motion Unit (SMU) but no parameters are assigned, the following message appears: “SMU not active, no parameter set”. The button directs to the page where the parameters are set.



4.6.2 Modification of Safety Parameters

The safety parameters can be modified with WebMotion® and the functional safety login:

Enter IP address of the XENAX® servo controller and add „/SAFETY.html“ in Web browser.
E.g. <http://192.168.2.190/SAFETY.html>



Password: **SafetyXvi75V8**
„OK“

Note: Please pay attention to capital and small letters.



Actual
Current safety parameters of XENAX® servo controller with SMU.

New
This is where new safety parameters can be selected from the drop down menu. They are activated in XENAX® servo controller by pressing „save“.

save
to XENAX®:
The modified safety parameters are being sent to XENAX® / SMU. The active parameters are visible in the column XENAX®.


to File:
The safety parameters on the SMU are saved into a file.

open
Safety parameters can also be loaded from a pc file. In order to be activated on the XENAX® servo controller, the parameters have to be saved by pressing on the *save* → to XENAX.

ED x 1000
The Parameter ED „Emergency Deceleration“ muss be set as big, that STOP and SLS Timeout can be hold by stopping.

By pressing „EXIT“ you exit functional safety and get back to WebMotion®.

Note: The Signal of an active safety function has to be operated by a higher level control system.



5 UL

For UL-conformity, the XENAX® servo controllers need to be used with the Brake Energy Converter from Jenny Science AG to guarantee voltage levels during dynamic braking within DVC A Levels.

Please refer *Manual_Brake_Energy_Converter.pdf*

5.1 Ratings


Description	Data
Input (PW) Input (LG)	24 – 36 VDC max. 6.93 A 15.59A peak 24 VDC max 1.3 A
Output (Motor)	0 – 25.5V ac, 3phase, 5.7A, 18A peak
Power Supply	These products are intended for operation within circuits not connected directly to the supply mains (galvanically isolated from the supply).
	The XENAX® Servocontroller/s need to be used with the Brake Energy Converter to stay within the 36 DVC A Limits
	Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes. For Canada (ENG): Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Canadian Electrical Code, Part I. For Canada (F): Des protections intégrées, à relais statique, contre les court circuits, ne protègent pas contre les circuits de dérivation. Une protection contre les circuits de dérivation doit être fournie conformément au code canadien de l'électricité, Partie I.
Maximum Surrounding Air Temperature	+ 45°C
Temperature Wago Connectors	-60°C ... 100°C
Temperature Rating of field installed conductors	-25°C ... 80°C
Motor Overload Protection for motors other than the LINAX® / ELAX® Linear Motors	External or Remote Motor Overload Protection and overtemperature sensing need to be provided.
Motor Overload Protection for the LINAX® / ELAX® Linear Motors	The proper connection and the rating of the load imposed by the equipment on the protector contacts. Power output: 0-25.5 VAC, 3 phase, 5.7 A, 18 A peak
UL File Nr.	E477533, Link to file , Link to file Canada

6 Electrical Connections

Note:

Only connect or disconnect any electrical connector with power supply disconnected.

XENAX® Xvi 75V8



6.1 Plug Arrangement

Description	Plug Type
RS232	USB-B socket
Real time Ethernet (optional)	2 x RJ45 socket with status LED
CANopen (optional)	9 Pol socket D-Sub
Ethernet TCP/IP	RJ45 socket with status LED
MOTOR	3 pole plug Wago, pitch 3,5mm
POWER / LOGIK	4 pole plug Wago, pitch 3,5mm
ENCODER HALL	15 pole plug D-Sub High Density
OPTIO	8 pole socket RJ45
PLC I/O	26 pole plug D-Sub High Density
START-UP / MASTER-SLAVE	2 x 4 pole plug USB-A


6.2 Plug Pin Configuration

6.2.1 RS232

USB-B Socket

The serial interface RS232 is led over a 4 pole USB-B socket.

USB Socket	XENAX®	PC/SPS
1	N.C.	
2	RX	TX
3	TX	RX
4	GND	GND



6.2.2 Motor Plug 3 Phase

Wago 3 Pole Plug		LINAX® / ELAX® 3 Phase	Servo motor 3 Phase	DC Motor
1		U (white)	U	DC +
2		V (brown)	V	DC -
3		W (green)	W	

6.2.3 Logic and Power Supply

Wago 4 Pole Plug			
1		0, GND	Adapter logic
2		24V DC	
3		0, GND	Adapter power
4		12-75V DC	

The typical POWER supply is 24V DC. For the stronger LINAX® F40 / F60 axes with high masses (>2kg) or high dynamics (>1.5m/s) a POWER supply of 48V or 72V DC is applicable. The current consumption per axis can be up to 8A and 18A peak per axis. Depending on mass in motion, profile and power supply voltage.


For a fuse protection of the power supply it must be considered that a short peak current of 8A can be reached for the rotating field adjustment.

For a detailed calculation of the required power supply in your application, please contact our support <https://www.jennyscience.ch/en/contact/support>.

Important: The 0 volt connection of the logic supply (pin 1) and the 0 volt connection of the power supply (pin 3) have to be connected to the ground/chassis star point of the switch cabinet.

Note:

In case of emission sensitivity it is recommended to twist the supply cable for logic and power.



6.2.4 Encoder and Hall Signals

15 pole D-Sub socket	Signal	Description
1	GND	Together, for encoder and hall 0V supply, only 1 pin
2	5V Encoder	150 mA for encoder supply
3	Encoder A	Pull up 2,7kΩ to 5V, differential input 26LS32
4	Encoder A*	Middle level: pull up 2,7kΩ to 5V, Pull down 2,2kΩ, differential input 26LS32, 330Ω internal between Pin3/4
5	Encoder B	Pull up 2,7kΩ to 5V, differential input 26LS32
6	Encoder B*	Middle level: pull up 2,7kΩ to 5V, pull down 2,2kΩ, differential input 26LS32, 330 Ω internal between Pin5/6
7	Encoder Z	Pull up 2,7kΩ to 5V, differential input 26LS32
8	Encoder Z*	Middle level: pull up 2,7kΩ to 5V, pull down 2,2kΩ, differential input 26LS32, 330 Ω E internal between Pin7/8
9	HALL 1	Pull up 2,7kΩ to 5V, differential input 26LS32
10	HALL 1*	Middle level: Pull up 2,7kΩ to 5V, pull down 2,2kΩ, differential input 26LS32
11	HALL 2 / -TMP	Pull up 2,7kΩ to 5V, differential input 26LS32 / over temperature signal motor
12	HALL 2*	Middle level: Pull up 2,7kΩ to 5V, Pull down 2,2kΩ, differential input 26LS32
13	HALL 3 / I2C_SCL	Pull up 2,7kΩ auf 5V, differential input 26LS32 / I2C clock signal
14	HALL 3*	Middle level: Pull up 2,7kΩ to 5V, pull down 2,2kΩ, differential input 26LS32
15	5V Hall / I2C_SDA	5V, 150 mA / I2C data signal

6.2.5 Definition of Rotating Direction for Servo Motors

	Sight on front surface motor shaft, turn the shaft clockwise, the meter has to count upwards
Switch encoder A/B Switch +/- motor power	Switch rotating direction for DC brush type servo motors
Switch encoder A/B Switch hall1 with hall3 Switch winding-phase 1 and phase 2	Switch rotating direction for 3phase brushless servo motors
Phase 1 to phase 2, 2 to 3 and 3 to 1 Hall 1 to hall2, 2 to 3 and 3 to 1	Switch phase connection for brushless servo motors without change of rotating direction

6.2.6 OPTIO Pulse/Dir, Second Encoder Channel

PULSE/DIRECTION CONTROL

Enter settings in menu *setup / basic settings*:
PULSE / DIRECTION CONTROL, MODE 2, as standard
Parameter MODE and INC PER PULSE

MODE	0-29	2
INC PER PULSE	1-50	5
SYNC RATIO	+/-x10	0
CARD IDENTIFIER	0-255	0

Signal	RJ45	OPTIO
GND internal	Pin 1	GND
5V internal	Pin 2	5V
Pull up 2,7kΩ to 5V, differential input 26LS32	Pin 3	PULS
Pull up 2,7kΩ to 5V, differential input 26LS32	Pin 4	DIRECTION
Middle level: Pull up 2,7kΩ to 5V, pull down 2.2kΩ, differential input 26LS32	Pin 5	DIRECTION*
Middle level: Pull up 2,7kΩ to 5V, pull down 2.2kΩ, differential input 26LS32	Pin 6	PULS*

ENCODER 2

Electronic gear, MODE 1, as standard
Parameter SYNCH RATIO 10 = 1:1

MODE	0-29	1
INC PER PULSE	1-50	0
SYNC RATIO	+/-x10	-5
CARD IDENTIFIER	0-255	0

Signal	RJ45	OPTIO
GND intern	Pin 1	GND
5V intern	Pin 2	5V
Pull up 2,7kΩ to 5V, differential input 26LS32	Pin 3	A
Pull up 2,7kΩ to 5V, differential input 26LS32	Pin 4	B
Middle level: Pull up 2,7kΩ to 5V, pull down 2.2kΩ, differential input 26LS32	Pin 5	B*
Middle level: Pull up 2,7kΩ to 5V, pull down 2.2kΩ, differential input 26LS32	Pin 6	A*

6.2.7 PLC I/O

Output

Signal	D-Sub	PLC Cable	PLC I/O
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 1	White	Output 1 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 2	Brown	Output 2 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 3	Green	Output 3 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 4	Yellow	Output 4 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 5	Grey	Output 5 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 6	Ping	Output 6 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 7	Blue	Output 7 (0/24V)
Source PNP: 24V/100mA, Sink NPN: open collect. 24V/400mA	Pin 8	Red	Output 8 (0/24V)

Input

24V Input, Ri 31k Ω	Pin 17	White-grey	Input 1
24V Input, Ri 31k Ω	Pin 18	Grey-Brown	Input 2
24V Input, Ri 31k Ω	Pin 19	White-pink	Input 3
24V Input, Ri 31k Ω	Pin 20	Pink-Brown	Input 4
24V Input, Ri 31k Ω	Pin 21	White-blue	Input 5
24V Input, Ri 31k Ω	Pin 22	Brown-blue	Input 6
24V Input, Ri 31k Ω	Pin 23	White-red	Input 7
24V Input, Ri 31k Ω	Pin 24	Brown-red	Input 8 (program Start)

24V Input, Ri 31k Ω / Bit 0 binary coded	Pin 13	White-green	Input 9
24V Input, Ri 31k Ω / Bit 1 binary coded	Pin 14	Brown-green	Input 10
24V Input, Ri 31k Ω / Bit 2 binary coded	Pin 15	White-yellow	Input 11
24V Input, Ri 31k Ω / Bit 3 binary coded	Pin 16	Yellow-Brown	Input 12


MODE ≥ 10 Input 9-12, binary coded, for program number 1-15, input 8 fix dedicated for program start (edge triggered)

MODE	0-29	12
INC PER PULSE	1-50	5
SYNC RATIO	$\pm \infty$:10	0
CARD IDENTIFIER	0-255	0

Enabling Power Stage

Activate the function with DIP-switch

ON
OFF



DIP switch OFF HW power stage enabling with 24V on Pin 9
Input open or 0V = power stage blocked

DIP switch ON Always enabling power stage, Pin 9 inactive
(Standard configuration)

Pin 9 black Enable PWR / Input

2A
24V / 80mA
24V / 200mA (total Pin 12+Pin 26)

Pin 10	violet	GND
Pin 11	Grey pink	Pulse Output (not implemented)
Pin 12	Red-blue	24V Output


2A
24V / 200mA (total Pin 12+Pin 26)

Pin 25	White-black	GND
Pin 26	Brown-black	24V Output

6.3 Internal I/O Circuit

INPUT 1-12

INPUT FUNCTIONS			
	ACTIVITY	FUNCTION	
INPUT 1	HIGH	REF	
INPUT 2	HIGH	PG	1
INPUT 3	LOW	EE	
INPUT 4	HIGH	---	
INPUT 5	HIGH	---	
INPUT 6	HIGH	---	
INPUT 7	HIGH	---	
INPUT 8	HIGH	---	



HIGH or LOW ACTIVITY programmable


OUTPUT 1-8

TYPE SOURCE

SOT Bit-value	TYPE	SOA Bit-value	ACTIVITY
0,1	SOURCE	1	HIGH
		0	LOW

Output ON 24V*
Output OFF open* 24V

All Output SOURCE
SOT 21845
SOA 255 / 0




TYPE SINK

SOT Bit-value	TYPE	SOA Bit-value	ACTIVITY
0,0	SINK	1	HIGH
		0	LOW

Output ON open
Output OFF 0V
open

All Output SINK
SOT 0
SOA 255 / 0




TYPE SOURCE/SINK

SOT Bit-value	TYPE	SOA Bit-value	ACTIVITY
1,0	SINK / SOURCE	1	HIGH
		0	LOW

Output ON 24V
Output OFF 0V
0V 24V

All Output SOURCE/SINK
SOT 43690
SOA 255 / 0



6.4 Output Configuration

TYPE

SOT (Set Output Type) parameter 16 Bit
2 Bit-value per output

COMMAND

SOT 21845

--- Recall commands ---

RESPONSE

SOT? 21845

Output	8		7		6		5		4		3		2		1	
SOT Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Bit-value	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
Decimal	21845															

*Default setting all output on SOURCE
>SOT 21845

ACTIVITY

SOA (Set Output Activity) parameter 8 Bit
1 Bit-value per output

COMMAND

SOA 255

--- Recall commands ---

RESPONSE

SOA? 255

Output	8	7	6	5	4	3	2	1
SOA Bit	7	6	5	4	3	2	1	0
Bit-value	1	1	1	1	1	1	1	1
Decimal	255							

*Default setting all output HIGH ACTIVE
>SOA 255

Parameter Values

Output	SOT Bit	SOT Bit-value	TYPE	SOA Bit	SOA Bit-value	ACTIVITY	Output ON	Output OFF
1	0,1	0,0	SINK	0	0	HIGH	0V	open
				0	1	LOW	open	0V
2	2,3	0,1	SOURCE	1	0	LOW	open	24V
				1	1	HIGH	24V*	open*
3	4,5	1,0	SINK/SOURCE	2	0	LOW	0V	24V
				2	1	HIGH	24V	0V

Examples

Output	SOT Bit	SOT Bit-value	TYPE	SOA Bit	SOA Bit-value	ACTIVITY	Output ON	Output OFF
1	0,1	0,0	SINK	0	0	HIGH	0V	open
2	2,3	0,1	SOURCE	1	1	HIGH	24V*	open*
3	4,5	0,1	SOURCE	2	1	HIGH	24V*	open*
4	6,7	0,1	SOURCE	3	1	HIGH	24V*	open*
5	8,9	1,0	SINK/SOURCE	4	0	LOW	0V	24V
6	10,11	1,0	SINK/SOURCE	5	0	LOW	0V	24V
7	12,13	1,0	SINK/SOURCE	6	1	HIGH	24V	0V
8	14,15	0,0	SINK	7	1	HIGH	0V	open

SOA 11001110_b 206_d
SOT 0010101001010100_b 10836_d

10836
0010 1010 0101 0100
15 0

Microsoft Windows
Version 6.1 (Build 7601)

7 Configuration Motor Type Jenny Science / Motor customer specific

The XENAX® Servo Controller differentiates between Jenny Science Motors LINAX® Lx, ELAX® Ex or ROTAX® Rx, and linear motors from other manufacturers.

The setting is done on the hardware over a DIP switch. The configuration is visible on the sticker with the serial number. The Jenny Science motors are automatically identified and parameterized.

Jenny Science Motors:
LINAX® Linear Motor Axis
ELAX® Linear Motor Slide
ROTAX® Rotary Axis


XENAX® Xvi 75V8
 EtherCAT, **Lx, Ex or Rx**
 SN Xvi-75V8.xxxx
 JENNY SCIENCE AG

Motors from other manufacturers
Typically rotary servo motors

XENAX® Xvi 75V8
 EtherCAT, **No JSC motor**
 SN Xvi-75V8.xxxx
 JENNY SCIENCE AG

Motor Type	Bit 1	Bit 2	Bit 3	Bit 4
LINAX® / ELAX® / ROTAX®	ON	ON	OFF	OFF
No JSC moto	OFF	OFF	ON	ON

A subsequent readjustment of motor type is possible through the according setup of the DIP-switch. A change in motor type should be updated on the sticker with the serial number.



Please note:


For the older hardware versions < 3, the DIP-switch is located on the opposite side of the circuit board.



8 RS232 Serial Interface

8.1 Baud Rate RS232 XENAX®

Setting the baud rate RS232 using the 8-bit DIP-switch (remove the cover to find the multi switch). The new baud rate will be activated after switching the device off and on again.




	Baud Rate	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7	Bit 8
	RS232 9600 baud	X	x	x	x	x	x	OFF	OFF
	RS232 115'200 baud (default)	X	x	x	x	x	x	OFF	ON
	RS 232 57'600 baud	X	x	x	x	x	x	ON	OFF
	RS232 19'200 baud	X	x	x	x	x	x	ON	ON
Data	8 Bit								
Parity	No								
Stop	1 Bit								

9 ETHERNET TCP/IP Interface

Please also consult the TUTORIAL VIDEO **JSC Tutorial 1: TCP/IP Connection** on our website, in which you can see all possible obstacles and according measures to solve the problems which might occur during the TCP/IP connection.

If the error "connection to Gateway (Port 10001) refused" occurs when opening WebMotion® there might be the following causes:

- WebMotion® is opened twice with the same TCP/IP address
- Baud rate of XENAX® does not correspond to baud rate in XPort
- Setup records are wrong




9.1 Baud Rate Ethernet Gateway (XPort)

Important:

On operation with WebMotion® the baud rate of XPort (Ethernet gateway) must be in accordance with the baud rate of XENAX® (Default 115'200)

Start tool „[DeviceInstaller](#)“ and search for desired XPort.




Click on IP-address, choose „Telnet Configuration“, press “Connect” button and confirm with “Enter” key.

Choose selection 1 (Channel 1) and set baud rate according to XENAX® setup. Confirm all other menu items with “Enter” key.

Save setup with selection 9 (Save and exit).

Close Tool “[DeviceInstaller](#)” and start WebMotion®.




IP-address of XENAX® is provided on the back side of the controller.

Connection of XENAX® to laptop/PC over a normal RJ45 network cable.

When connecting laptop/PC directly to XENAX®, it may possibly need a crossed RJ45 cable. However, with newer network types a crossed RJ45 cable is not necessary anymore.

Display Ethernet Plug

Color	LED left	Color	LED right
Off	No connection	Off	No Activity
Orange	10Mbps	Orange	Half-duplex
Green	100Mbps	Green	Full-duplex




9.2 Default Setup Records Upgrade

Open DeviceInstaller


Connect XENAX® with Ethernet cable and power.
Open DeviceInstaller and choose the according
XENAX® servo controller.

Upgrade Setup Records

Upgrade Setup Records in DeviceInstaller



-> Next >
->Next >




Select:

- Install setup records from a file


Choose File „Xvi_SetupRecords_115200.rec” with
„browse“. (This file can be downloaded from
<http://www.jennyscience.de/en/download/> under
Servo Controller / Setup Records)

->Next >
->Next >



The new setup is being upgraded and is completed
when colored in green.

Close.



9.3 Test IP Connection with >IPCONFIG

IPCONFIG command in DOS window

Test TCP/IP address range.

IP address has to be in range of 192.168.2.xxx
If necessary adjust IP address in computer „network environment“ to e.g. IP 192.168.2.200.

xxx = 001 – 255

≠ IP Address XENAX®

```
Verbindungsspezifisches DNS-Suffix:
IP-Adresse (Autokonfig.) . . . . . : 192.168.2.200
Subnetzmaske . . . . . : 255.255.255.0
Standardgateway . . . . . :
```

9.4 Test Connection with >PING

PING command in DOS window

IP address is provided on the back side of XENAX®.
If no response, check direct connection with crossed

RJ45 cable.

If you do not know the IP address, you can look it up
with the [DeviceInstaller](#), provided that the Ethernet
connection is working o.k.

```
C:\Dokumente und Einstellungen\ping 192.168.2.100
Ping wird ausgeführt für 192.168.2.100 mit 32 Bytes Daten:
Antwort von 192.168.2.100: Bytes=32 Zeit<1ms TTL=64
Antwort von 192.168.2.100: Bytes=32 Zeit<1ms TTL=64
Antwort von 192.168.2.100: Bytes=32 Zeit<1ms TTL=64
Antwort von 192.168.2.100: Bytes=32 Zeit<1ms TTL=64
Ping-Statistik für 192.168.2.100:
    Pakete: Gesendet = 4, Empfangen = 4, Verloren = 0 (0% Verlust)
    Ca. Zeitangaben in Millisek.:
        Minimum = 0ms, Maximum = 0ms, Mittelwert = 0ms
```

9.5 Change IP Address with “Device Installer”

To view and change the IP address as well as to
update WebMotion®, the [DeviceInstaller](#) tool is used.


Use link on the right and click on [DeviceInstaller](#).

Select XPort and install it.

The DeviceInstaller needs .NET Framework driver.

Search IP address


Start DeviceInstaller von Lantronix from Lantronix
and select “Search” to look for existing IP addresses.



Change IP address

On “Assign IP” select “Assign a specific IP address”.

Now you can set a new IP address.




9.6 Change Port Number with “Device Installer”

To communicate with WebMotion® and higher control systems via Ethernet TCP/IP, XENAX® is delivered with the default XPort settings on the right.

The parameters can be changed with the tool DeviceInstaller in menu „Telnet Configuration“.

You can reset the parameters to default settings manually or by uploading the setup-record file (on request).



We recommend strongly using the default XPort settings. Otherwise, the correct functionality of WebMotion® and the communication over Ethernet cannot be guaranteed.

```
*** Channel 1
Baudrate 115200, I/F Mode 4C, Flow 01
Port 10001
Connect Mode : C0
Send '+++' in Modem Mode enabled
Show IP addr after 'RING' enabled
Auto increment source port disabled
Remote IP Addr: --- none ---, Port 00000
Disconn Mode : 00
Flush Mode : 80
Pack Cntrl : 10
SendChars : 0A 3E
```

The default port number is 10001. WebMotion® addresses this port as a standard.

If another port number has to be communicated, the port number has to be set antecedently on XPort.

Example: Connection on port number 10005

When starting WebMotion® in the web browser window, this port address has to be entered according to the following syntax:

```
*** Channel 1
Baudrate 115200, I/F Mode 4C, Flow 01
Port 10005
.....
.....
```

Starting WebMotion®


<http://192.168.2.xxx/xenax.html?Port=10005>

9.7 Close Port

If the port 10001 is not closed correctly it can stay open. In this case, it is no longer possible to connect to this port with a new TCP/IP connection


There are 3 options for closing the port again.

1. Disconnect the Ethernet cable directly on the Xenax Xvi 75V8 and the port will be closed automatically.



2. A TCP/IP connection over the port 9999 or the [DeviceInstaller](#) can also close the port. Use the „Telnet Configuration“ tab in the DeviceInstaller.


- Open Port 9999
- Send <CR> (carriage return), the menu text will be printed in the console.
- Send <9>, <CR> (save and exit)



3. Set a timeout with [DeviceInstaller](#)

- Open port 9999
- Send <CR> (by pressing enter), the menu text will be printed in the console.
- Select <1> and press enter
- Press enter multiple times until DisConnTime appears.
- Input timeout minutes e.g. 00
- Press enter, this switches to minutes
- Input timeout seconds e.g. 40
- Press enter until the menu appears again
- Save changes by pressing <9> and enter

The forces a client on port 10001 to send a <CR> every 40 seconds or the Port will be closed automatically.



10 ASCII Protocol

Over Ethernet TCP/IP in the menu *move axis / by command line* in WebMotion® or via the serial interface e.g. with hyper terminal.

The simple ASCII protocol works with the echo principle. The sent characters come back as an echo and can be checked immediately. Thus, if existing, you get a parameter value and finally the character prompt ">". If the command could not be accepted then, it has a "?" character in the string.

Description	Command	[Parameter]	Echo command accepted
<i>Write parameters:</i>			
Power continues	PWC	<CR>	PWC <CR> <LF> >
Speed	SP	10-9'000'000 <CR>	SPxxxxxx<CR> <LF> >
Acceleration	AC	2'000-100'000'000 <CR>	ACxxxxxx<CR> <LF> >
<i>Read parameters:</i>			
Tell Position	TP	<CR>	TP <CR> <LF> XXXXXX<CR> <LF> >
Retrieve	e.g. AC?	<CR>	AC? <CR> <LF> XXX <CR> <LF> >
	SP?	<CR>	SP? <CR> <LF> XXX <CR> <LF> >

Echo command not recognized or cannot be completed in the current configuration
 <command> <CR> <LF> ? <CR> <LF> >

Echo command cannot be accepted at this time
 <command> <CR> <LF> #xx <CR> <LF> >

#-List

Nr.	Description
#01	Error in queue
#03	Drive is active
#05	Program is active
#13	EE1 in queue
#14	EE in queue
#15	Force Calibration active
#27	I Force Drift Compensation active
#34	Rotary reference active
#36	Gantry reference active
#38	Reference active
#40	Command at active bus module not allowed
#47	Fault Reaction active
#49	No JSC Motor detected
#65	Value of parameter not valid
#66	Command not completed correctly (>5s between ASCII-signs)

Note for sequential commands:
 Terminate a command with <CR> only, no additional <LF>. Do not send a new command until you have received the prompt character „>“ before.

10.1 ASCII Protocol TCP/IP

In TCP/IP the cohesive ASCII sequences can be splitted into different telegram packages. This is why a separate receive buffer has to be considered.

Please find detailed information in:

„Xvi75_TCP/IP_Socket_Telegram_Events/Wireshark.pdf“

on <http://www.jennyscience.de/en/download/>.

10.2 Asynchronous Messages (Events)

To reduce response time, status or PLC input modifications of the PLC interface can be sent automatically (events). Therefore it is not necessary to poll the status or inputs permanently.

Enable Events

Events disabled, default	EVT=0
Events enabled generally	EVT=1

Status modifications / Reference Event

Will be sent in case of generally activated events.

Power OFF	@S0
Power ON / Halt	@S1
In motion	@S2
Error	@S9
Reference finished	@H

PLC Input

Inputs are selectable with ETI (Event Track Input)

Enable event of input 1..12	ETI=1..C
Enable all input events	ETI=0

Disable event of PLC input with DTI (Disable Track Input).

Disable event for input 1..12	DTI=1..C
Disable all input events	DTI=0

Structure of input events @Ixyz
with xyz as half bytes in Hexadecimal notation.

PLC I/O pin no.	16	15	14	13	24	23	22	21	20	19	18	17
INPUT no.	12	11	10	9	8	7	6	5	4	3	2	1
Example input bits after modification	1	0	1	1	0	0	1	0	1	1	0	1
Event general @I	x				y				z			
Example Event @I	"B"				"2"				"D"			

Default Settings after Power ON

After power on of XENAX® servo controller or application download, default settings are active again:

Events OFF EVT=0
 PLC Input Events OFF DTI=0

11 Install JAVA Plugin

Check installed JAVA version.

The JAVA Plugin Software version has to be higher or equal version 7.

Information on the installed JAVA version can be retrieved under:

Start / Control Panel / JAVA / General / Info.

We highly recommend uninstalling older JAVA versions before installing the new version.



Download Java

<http://www.java.com/de/download/manual.jsp>




11.1 Applet Cache


The WebMotion® applet should be fully reloaded by each new start of the browser or when the browser is being updated. To prevent problems and errors during the loading process, the Cache option has to be deactivated.

Open JAVA Control Panel:
Start / Control Panel / JAVA

Temporary Internet Files




Deactivate "Keep temporary files on my computer".



11.2 Disable Java certificate Validation

If the XENAX® servo controller is connected to a PC without internet access, the Java certificate cannot be validated. This can possibly slow down loading the WebMotion® user interface or can even lead to a time-out. The automatic certificate validation has to be deactivated.

Open the control panel of the PC → Java → Advanced
→ uncheck „Enable online certificate validation“.



12 WebMotion®

Please also consult the TUTORIAL Video
JSC Tutorial 2: Set-Up Single Axis on our website and
 convince yourself of the easy axis setup with
 WebMotion®.

WebMotion® is an integrated graphic user
 interface (website), located in XENAX®.

It is loaded and activated over a web browser. A
 certain Version of the Java Plugin is required for that.

The installation of the Plugin is described in the
 previous chapter. However, must browsers do not
 support Java anymore. Because of this, Jenny Science
 provides a modified version of the Qupzilla Browser
 with integrated Java plugin. This Browser can be
 downloaded from JennyScience.ch.

Note:

Please make sure that zoom-settings of the browser
 window are at 100% (original size). Otherwise the
 WebMotion® display is affected.

12.1 Start WebMotion®


Start your web browser with the IP address number of
 your XENAX® and add “/xenax.html” as a suffix.

IP address is provided on the back side of the XENAX®.

Example:

<http://192.168.2.xxx/xenax.html>


XENAX® is being started with an automatic system self-
 check including type designation and version information
 on firmware and hardware. Moreover, WebMotion®
 identifies the connected linear motor or rotary motor and
 uploads the current XENAX® settings (parameters,
 programs) in to the WebMotion®.



Interruption of TCP/IP Connection

If the XENAX® logic supply is interrupted or if the Ethernet cable is disconnected, the TCP/IP interruption will be detected by WebMotion® and signaled with “offline”. After removing the cause of the offline-mode, the TCP/IP connection has to be reloaded by updating the current web browser window.


If it is still blocked, it is recommended to first exit and then restarts the web browser.



12.1.1 Error „Upload XENAX Settings“

The settings in Kaspersky Internet Security might be responsible if the error code „Error Upload XENAX Settings“ occurs with the automatic self-check of WebMotion®.

If you are using Kaspersky or similar internet security software, the security for Instant Messenger Services has to be deactivated.
(Refer example in Kaspersky Pure 3.0)



12.2 Quick Start (only with LINAX® and ELAX® linear motor axes)


The Quick Start function allows the user to setup the LINAX® or ELAX® linear motor axis with the XENAX® controller simply immediately after receipt of the components.

It is completed per mouse click, without parameter settings and without an instruction manual.

By pressing the Quick Start button, a system check is automatically started including the following tests:

Cable connections, power voltage, input functions, functionality of the measuring system, parameter settings and current flow of the linear motor.

In order to test the functionality of the measuring systems the system asks you to move the slider of the LINAX® linear motor axis of a distance of at least 20mm back and forth.



With the START the LINAX® or ELAX® linear motor will be referenced automatically and will then move the distance back and forth that was indicated manually by hand before.

For the Quick Start Function it is recommended to operate the linear motor axis in horizontal orientation without a payload.



You can adjust the dynamics individually with the arrow symbol by mouse click.



12.3 Operation, Status Line

The status line on the lower edge of WebMotion® gives an overview of the current condition of XENAX® and the connected motor at any time. These data cannot be changed and are for the user's information only.

MOTOR TMP

Shows the current temperature of the coils in the LINAX® / ELAX® / ROTAX® motors, which is detected by a sensor. This measuring function is not possible for rotary servo motors. The temperature observation for servo motors is done by an I²T calculation. For linear motors the I²T observation is performed in addition to the motor temperature measurement.

POSITION

After referencing, this indicates the absolute position of the motor in increments of the measuring system.

Standard for LINAX® / ELAX® linear motors is
1 Increment = 1 µm.

MOTOR

Automatic identification of the connected LINAX® / ELAX® / ROTAX® motor axis. If a third-party rotary motor is connected, "ROTATIVE" is displayed.

REFERENCE

The reference is a condition to start the LINAX®/ELAX® linear motor axes. This is also how the precise current commutation is being calculated.

PENDING = Reference outstanding

DONE = Reference completed

MODE

Displays the operating mode:

0=Standard Servo

1 = El. Gera mechanism over second encoder

2 = Pulse/Dir, stepper emulation

10 = Coded Prog No Standard

12 = Coded Prog no for Stepper Controlled

STATUS

POWER OFF = off

POWER ON / HALT = On, Motor is not moving

IN MOTION = Motor is in motion

ERROR XX = error number, with a button that details the error and shows error history.

INPUT

Condition of the direct inputs 1-8, and the binary coded inputs 9-12.



OUTPUT

Condition of outputs 1-8
(Modification under menu *application* / I/O)

PROG

Program number, binary coded from inputs 9-12.
For this binary coded program selection, the MODE has to be set on higher or equal 10, while input 8 is the trigger for program start.

12.4 Move Axis by Click**12.4.1 Move Axis by Click for LINAX®/ELAX® Linear Motors**

Simple online control for setup and test of the linear motor axes.

The orange values behind the empty fields show the current registered values in XENAX®. New values can be entered in the empty fields and registered with <Enter>. These parameters will overwrite the existing values and will be registered directly in the XENAX® servo controller.

SOFT LIMIT POS

Software Limit Position, setting of an individual motion range in increments.

SLP- = position counter lower values

SLP+ = position counter upper values

Both values 0 = No limit (limit is the stroke of the connected linear motor)

S-CURVE %

Percentage S-curve rounding of the internal motion profile, e.g. in an INDEX, generally for all motion profiles. Automatic calculation of jerk (changing of acceleration per time unit inc/s^3)

ACC *1'000

Acceleration in inc/s^2 multiplied with a factor of 1'000

SPEED

Speed in inc/s

SP OVERRIDE %

Override of the set speed and acceleration of a motion profile, for example for process deceleration or set up mode.



Go Way (REL)

Input of the distance relative to the present position in increments. Start with <Enter>.

Go Position (ABS)

Input of the position absolute to the zero point in increments. Start with <Enter>.

Rep Reverse

Endless automatic motion back and forth.

Input of the way relative to the present position in increments. Start with <Enter>.

While running, the motors parameters such as acceleration, speed, and wait time can be adjusted online. Stop the back and forth movement with “Stop Motion”.

Wait Reverse

Wait time at reversal point of rep reverse in units of 1 milliseconds. Start with <Enter>.

TIME (ms)

Time of the last profile drive in milliseconds.

Reference

Reference-drive (>REF)

Executes the reference-drive to calculate the absolute position.

Run this function once after switching on the power.

Go Pos 0

(>G0) Go to position 0.

Power Cont

Power continues (>PWC)

Turning on the power stage with taking over the most recent absolute position and **without the need of referencing the linear motor, e.g. after error 50 or after “Power Quit”**. This is only possible as long as the logic supply has not been interrupted after the linear motor was referenced.

Stop Motion

Stops the motion under control of deceleration ramp.


Power Quit

Power stage without power, the linear motor is movable by hand.



12.4.2 Move Axis by Click for ROTAX® Rotary Motor or Third Party Motors

The XENAX® Servo Controller automatically recognizes the ROTAX® rotary motor.



If the XENAX® servo controller does not recognize a LINAX® or ELAX® linear motor axis or a ROTAX® rotary axis, XENAX® assumes a connection with third party motor. Instead of “Go Pos 0” WebMotion® offers Jog + und Jog – functions.


Jog -

Runs the motor in negative direction until the command “Stop Motion” stops the motor.

Jog +

Runs the motor in positive direction until the command “Stop Motion” stops the motor.

While the motor is running with Jog, the dynamics SP OVERRIDE or SPEED can be adjusted online.



12.5 Move Axis by Command Line

The XENAX® can directly be controlled by a ASCII command set.

COMMAND

Transmits an ASCII command with <Enter>. Under "Recall commands" the activated commands are saved and can be reactivated by mouse click

RESPONSE

shows received characters by WebMotion®.

COMMAND SET

Lists all ASCII commands, recognized by XENAX®.



12.6 ASCII Command Set for XENAX®

Using the simple ASCII command [+PARAMETER] set, all XENAX® Servo controller functions can be activated with an extremely short reaction time.

Information about the tables:

- ¹⁾ *Diagnosis and test functions*
 ? *Query of the programmed value*


12.6.1 Power / Reset

DESCRIPTION	Short	CMD	PARAMETER
Power ON incl. reset encoder counter	Power	PW	
Power ON continue, keep encoder counter	Power continue	PWC	
Power OFF servo amplifier	Power quit	PQ	
Reset setup parameters to default values	Reset	RES	
Reset motor parameters to default values for the currently connected motor (other parameters remain unchanged)	Reset Motor	RESM	
Clear actual position counter, (not possible with LINAX®/ ELAX®, with ROTAX® only possible if it is not referenced)	Clear position to 0	CLPO	
Deactivate blocking by unconfigured SMU (Until next power-cycle)	Disable Motion blocked by unconfigured SMU	DMBUS	

12.6.2 Basic Settings

DESCRIPTION	Short	CMD	PARAMETER
Set up of MODE (Operating) Important! In case of changing this value, the servo amplifier must be in state POWER OFF (>PQ)..	Mode	MD	0, 1, 2, 10, 12 / ? refer chapter 0 "Basic Settings"
Inc. per pulse, MODE 2/12, pulse/direction control	Inc per Pulse	ICP	1-50
Synchronous ratio for electronic gear	Synchronous Ratio	SR	± 1-1'000 : 10
Set CI (query), CANopen Node ID, Powerlink Node ID, Remote ID in Master/Slave Configuration	Card Identifier	CI	1-99 / ?
Card Identifier of Gantry Slave	Gantry Slave Identifier	GSID	0 - 4
Identification string max 16 characters free for user	Servo controller ident.	SID	string / ?

12.6.3 Motor Settings

DESCRIPTION	Short	CMD	PARAMETER
Max. motor current nominal [x10mA]	I stop	IS	10-1'800 / ?
Max. motor current peak [x10mA]	I run	IR	10-1'800 / ?
Pole-pair number of motor	Pole pair	POL	1-100 / ?
Number of encoder increments per revolution	Encoder	ENC	10-32'000 / ?
Direction of phase control (u,v,w or v,u,w)	Phase Direction	PHD	0,1 / ?
Detection of phase control sequence. By rotating the motor clockwise, 0 or 1 appears. Parameter can be used to enter the phase control (PHD).	Phase Direction Detection	PHDD	0, 1, ?
 If "?" appears, the Dip-switch is set to linear in the XENAX® servo controller or the hall wiring is wrong.			
Correction of the electrical angle at new adjustment of coils to magnets.	Phase Offset	PHO	0-359 / ?
Force constant of the motor for LINAX®/ELAX® in [mN/A], torque constant for rotary motors in [µNm/A]	Force Constant Motor	FCM	0-100'000'000 / ?
Resistance phase to phase of the motor in [mΩ]	Phase to Phase Resistance	RPH	0-100'000 / ?
Inductance phase to phase of the motor in [µH]	Phase to Phase Inductance	LPH	0-100'000 / ?
Gear ration of rotary Jenny Science motors (ROTAX)	Gear Ratio	GR	?

12.6.4 Controller Settings

DESCRIPTION	Short	CMD	PARAMETER
Payload "PAYLOAD" [g] or moment of inertia „INERTIA“ [x10 ⁻⁹ kgm ²]	Mass Load	ML	0-100'000'000 / ?
Bandwidth position controller "GAIN POS"	Bandwidth Position	BWP	1-5'000 / ?
Bandwidth current controller "GAIN CUR"	Bandwidth Current	BWC	5-5'000 / ?
Notch-Current filter frequency "Avoid Vibration FREQ NOTCH"	Filter Frequency Current	FFC	0-, 160-2'000 / ?
Notch-Current filter quality factor	Filter Quality Current	FQC	500-100'000 / ?
Active-Current filter frequency "Avoid Vibration FREQ ACTIVE"	Avoid Vibration Frequency	AVF	0-, 200-2'000 / ?

Damping coefficient settings in % of Active-Current filter	Avoid Vibration Damping	AVD	1-50 / ?
Max. position deviation in increments "Deviation POS ACT"	Deviation Position	DP	1-1'000'000 / ?
Permissible target point deviation "Deviation TARGET"	Deviation Target Pos.	DTP	1-10'000 / ?
Speed filter frequency	Filter Frequency Speed	FFS	0-, 160-2'000 / ?
Speed filter quality factor	Filter Quality Speed	FQS	500-100'000 / ?
Restore controller settings to behaviour smaller or equal to firmware V4.04D	Enhanced Bandwidth Mode Disable	EBMD	0-1 / ?
Controller Stability Settings "STAB – DYN"	Pole Placement Stability Dynamic	PPSD	± 50 / ?
Damping coefficient settings in % for swing out time reduction	Swing Out Reduction Damping	SORD	0-50 / ?
Frequency settings in 0.1Hz (21 => 2.1Hz) for swing out time reduction	Swing Out Reduction Frequency	SORF	0-, 20-1000 / ?

12.6.5 Motion Settings

DESCRIPTION	Short	CMD	PARAMETER
Position rated absolute, Inc	Position	PO	± 2'000'000'000 / ?
Position soll (absolute) increment, initial value after powerup	Position Initial Value	POI	± 2'000'000'000 / ?
Way relative, encoder increment	Way	WA	± 2'000'000'000 / ?
Way (relative) encoder Inkrement, initial value after powerup	Way Initial Value	WAI	± 2'000'000'000 / ?
Speed Inc/s (encoder counter)	Speed	SP	10-9'000'000 / ?
Speed Inc/s (encoder counter) , initial value after powerup	Speed Initial Value	SPI	10-9'000'000 / ?
Acceleration Inc/s ² (encoder counter)	Acceleration	AC	2'000-1'000'000'000 / ?
Acceleration Inc/s ² (encoder counter) , initial value after powerup	Acceleration Initial Value	ACI	2'000-1'000'000'000 / ?
Emergency Deceleration Inc/ s ² (e.g. for input function EE/EE, for errors, if driving in limit switch or soft limit etc.) If necessary the emergency deceleration can be adjusted during operation if there is an emergency deceleration of >1s → In case of emergency the deceleration is always <1s	Emergency Deceleration	ED	10'000-1'000'000'000 / ?
Override, scaling from the Acceleration and Speed	Override	OVRD	1-100 / ?
Override, scaling from the Acceleration and Speed, initial value after powerup	Override Initial Value	OVRDI	1-100 / ?
Percentage S-Curve rounding. Calculation of jerk parameter automatically.	S-Curve	SCRV	1-100 / ?
Percentage S-Curve rounding. Calculation of jerk parameter automatically, initial value after powerup.	S-Curve Initial Value	SCRVI	1-100 / ?
Jerk of trajectory [x1000Inc/s ³]	Acceleration Variation (Jerk), Read only	ACV	/ ?
Limitation driveway left Take effect by LINAX®/ELAX® motors only	Soft Limit Position Negative	SLPN (Old: LL)	0 - < LINAX®/ELAX® stroke > / ?
Limitation driveway right Take effect by LINAX®/ELAX® motors only	Soft Limit Position Positive	SLPP (old: LR)	0 - < LINAX®/ELAX® stroke > / ?

12.6.6 Reference LINAX® / ELAX®

DESCRIPTION	Short	CMD	PARAMETER
Home linear motor axis encoder	Reference	REF	
Start direction REF function 0 = positive, 1 = negative 2 = Gantry REF positive, motors same direction 3 = Gantry REF negative, motors same direction 4 = Gantry REF positive, motors reverse direction 5 = Gantry REF negative, motors reverse direction	Direction REF	DRHR	0-5 / ?

12.6.7 Reference Gantry

DESCRIPTION	Short	CMD	PARAMETER
Card Identifier of Gantry Slave set in the Master Control	Gantry Slave Identifier	GSID	0 - 4
Set CI (query), CANopen Node ID, Powerlink Node ID, Remote ID in Master/Slave Configuration	Card Identifier	CI	0-99 / ?
Home linear motor axis encoder	Reference	REF	
Start direction REF function 0 = positive, 1 = negative 2 = Gantry REF positive, motors same direction 3 = Gantry REF negative, motors same direction 4 = Gantry REF positive, motors reverse direction 5 = Gantry REF negative, motors reverse direction	Direction REF	DRHR	0-5 / ?
Responds the automatically detected Gantry Master Slave Offset. Important: The command DGMSO has to be performed on the Gantry Slave Axis.	Detected Gantry Master Slave Offset	DGMSO	
Indication of the Gantry Master Slave Offset. Deviation to the automatically detected value max. 0.5mm, otherwise error 76. 0 = use automatically detected value, can be read with DGMSO . <> 0 = User pre-set Gantry Master Slave Offset Important: The command has to be performed on the Gantry Slave Axis.	Preset Gantry Master Slave Offset	PGMSO	+/- 5'000'000 / ?

12.6.8 Reference Rotary Motors

DESCRIPTION	Short	CMD	PARAMETER
Home function according to program	Reference	REF	
Direction of motor rotation to seek external coarse sensor, 1 = CW, 2 = CCW	Dir Home	DRH	1-2
Speed for seeking external sensor If there is no external sensor, then set SPH = 0	Speed Home	SPH	0-25'000 Inc/s
Input number for external Home Sensor 0 = None, 1-8 = Input Number	Input Home	INH	0-8

Rotary direction of motor for seeking z-mark on encoder, 1 = CW, 2 = CCW 3 = shortest way (for ROTAX® Rxvp only)	Dir Z-Mark	DRZ	1-2
Speed for seeking z-mark If there is no z-mark on the encoder, set SPZ = 0 (only possible for 3th party motors, not for ROTAX®)	Speed Z-Mark	SPZ	0, 10-10'000 Inc/s
Position of Z-mark in reference to internal home sensor of ROTAX® Rxvp. Will be saved after first reference and remains from then on unchanged. With RXZP0 this value can be deleted and ROTAX® Rxvp will be set to default at time of delivery.	Rotax Z-Mark Position	RXZP	0 / ?

12.6.9 Move Commands

DESCRIPTION	Short	CMD	PARAMETER
Go direct to rated position absolute, Inc	Go direct Position	G	± 2'000'000'000
Go to position absolute	Go Position	GP	(Position = PO value)
Go way relative	Go Way	GW	(Way = WA value)
Go to zero-mark on encoder disk	Go Z-Mark	GZ	
Jog (run) positive, v = constant	Jog Positive	JP	(Speed = SP value)
Jog (run) negative, v = constant	Jog Negative	JN	(Speed = SP value)
Repeat way(WA value) positive/negative	Repeat Reverse	RR')	1-100'000
Repeat way (WA value) constant direction	Repeat Way	RW')	1-100'000
Waiting time on command RR and RW	Wait Repeat	WT')	1-10'000 (ms)
Waiting time for command RR and RW, initial value after powerup	Wait Repeat Initial Value	WTI')	1-10'000 (ms)
Run index number	Index	IX	1-50
Run profile	Profile	PRF	1-5
Move DRIVE I_FORCE Nr. xx	Drive I Force	DIF	xx
Stop program and motion with deceleration	Stop Motion	SM	

12.6.10 Index / Moves with I_Force (programmed movements)

DESCRIPTION	Short	CMD	PARAMETER
Run index number	Index	IX	1-50
Number of index pre-load for changing index parameters by remote control	Number Index	NIX	1-50
Acceleration write in Index at the NIX preloaded number (stored in non-volatile memory, still effective after power cycle)	Accel. Index	AIX	2-1'000'000 (x1000) Inc/s ²
Acceleration write in Index at the NIX preloaded number (not stored in non-volatile memory, only effective until the next power cycle)	Accel. Index Dynamic	AIXD	2-1'000'000 (x1000) Inc/s ²
Speed write in Index at the NIX preloaded number (stored in non-volatile memory, still effective after power cycle)	Speed Index	SIX	10-1'000'000 Inc/s
Speed write in Index at the NIX preloaded number (not stored in non-volatile memory, only effective until the next power cycle)	Speed Index Dynamic	SIXD	10-1'000'000 Inc/s
Distance write in Index at the NIX preloaded number (stored in non-volatile memory, still effective after power cycle)	Distance Index	DIX	± 2'000'000'000 Increment

Distance write in Index at the NIX preloaded number (not stored in non-volatile memory, only effective until the next power cycle)	Distance Index Dynamic	DIXD	± 2'000'000'000 Increment
Save index type in index for the preselected number with NIX (1 = absolute, 2 = relative) (stored in non-volatile memory, still effective after power cycle)	Type of Index	TYIX	1,2 / ?
Save index type in index for the preselected number with NIX (1 = absolute, 2 = relative) (not stored in non-volatile memory, only effective until the next power cycle)	Type of Index Dynamic	TYIXD	1,2 / ?
Move with DRIVE I_FORCE Nr. xx	Drive I Force	DIF	xx
Selecting Drive I_Force number in which parameters shall be changed. xx= Drive I_Force number 1-10. NDIF? = Retrieving selected sector number	Number of Drive I_Force to change parameter	NDIF	Xx
Acceleration for Drive I_Force xx [x1'000 inc/s²]	Acceleration of selected Drive I_Force	ADIF	xx
Speed for Drive I_Force xx [inc/s]	Speed of selected Drive I_Force	SDIF	xx
Limitation of I-Force current while Drive I_Force xx [x10mA]	I_Force Limit of selected Drive I_Force	IDIF	xx
Direction Drive I_Force xx = 0 -> positive, xx = 1 -> negative	Direction of selected Drive I_Force	DDIF	xx

12.6.11 Program / Application

DESCRIPTION	Short	CMD	PARAMETER
Run program number	Program	PG	1-15
0 = Program 1..15 max. 50 program lines, Program 16..63 max. 10 program lines 1 = Program 1..5 max. 130 program lines, Program 6..63 max 10 program lines Important: Changes of PMAP parameter clears entire program memory	Program Mapping	PMAP	0,1 / ?
Save Application (incl. parameters) to Start-up Key	Save to Start-up Key	SVST	

12.6.12 Event

DESCRIPTION	Short	CMD	PARAMETER
Event activation	Event Status or Input	EVT	0,1
0=All input events enabled 1..C= Event of input 1..12 enabled	Event Track Input	ETI	0-9, A-C
0= All input events disabled 1..C = Event of input 1..12 disabled	Disable Track Input	DTI	0-9, A-C

12.6.13 Input / Output

DESCRIPTION	Short	CMD	PARAMETER
Set type of PLC outputs (Source, Sink, Source/Sink) -> refer chapter 6.4 Output Configuration	Set Output Type	SOT	0-65535
High / Low Activity of PLC outputs -> refer chapter 6.4 Output Configuration	Set Output Activity	SOA	0-255
Set PLC output to logic 1 (level according SOT, SOA)	Set Output	SO	1-8
Equivalent to SO, but set all outputs binary coded Bit 0 = Output 1, Bit 7 = Output 8	Set Output Hex	SOX	00-FF
Clear output (level according SOT, SOA)	Clear Output	CO	1-8
Status all Outputs, 0= logic 0, 1=logic 1	Tell Output	TO	
Status all Outputs in HEX format	Tell Output HEX	TOX	
Preload output number for output function assignment with command TYOF	Number Output Function	NOF	1-8
Assign type of output function to the with NOF preloaded output number (0 = no function, 1 = REF, 2 = INMO, 3 = EDPG, 4 = TGR, 5 = ERR, 6 = BRK, 7 = INPO, 8 = IFML, 9 = IFSE, 10 = INSE, 11 = INFO, 12 = WARN, 13 = INFM14 = STO1, 15 = STO2, 16 = SS11, 17 = SS12, 18 = SS21, 19 = SS22, 20 = SLS1, 21 = SLS2)	Type Output Function	TYOF	0-21
Trigger upward counting, absolute, at output #x defined in Output-Function, pulse during 5ms	Trigger upward	TGU	± 2'000'000'000 Increment
Trigger downward counting, absolute, at output #x defined in Output-Function, pulse during 5ms	Trigger downward	TGD	± 2'000'000'000 Increment
0=all Input HIGH active, 1= all Input LOW active, 2= individual input activity selection according to ILAS (value 0 and 1 puts ILAS to 0x000 respectively 0xFFFF)	Input LOW active	ILA	0-2 / ?
individual input activity selection, 0=Input HIGH active, 1=Input LOW active	Input Low Active Single	ILAS	0xx / Fxx / ?
1. Hex for value binary inputs 9-12 only 0 or F, 2. And 3. Hex value for input 1-8 (values 0x000 and 0xFFFF put ILA to 0 resp. 1. All other values are to 2 by ILA			
Status all inputs, 0 = Low, 1 = High / ? incl. indication of input number	Tell Input	TI	1-12 / ?
Status single input, 0 = Low 1 = High	Tell Input	TI	1-12
Status all Inputs in HEX format	Tell Input HEX	TIX	
Preload input number for input function assignment with command TYIF	Number Input Function	NIF	1-8
Assign type of input function to the with NIF preloaded input number (0 = no function, 1 = REF, 2 = IX, 3 = PG, 4 = SO, 5 = CO, 6 = JP, 7 = JN, 8 = CPOS, 9 = IP, 10 = SI, 11 = SIC, 12 = LS-, 13 = LS+, 14 = EE, 15 = EE1, 16 = PWC, 17 = PRF, 18 = RSTO, 19 = OVRD, 20 = PGEX, 21 = DIF, 22 = PQ)	Type Input Function	TYIF	0-22
Parameter A of input function of with NIF preloaded input number (value depending on input function, according to value described in chapter 12.13.1 Selection of Input Functions)	Parameter A	PAIF	xx
Parameter B of input function of with NIF preloaded input number (value depending on input function, according to value described in chapter 12.13.1 Selection of Input Functions)	Parameter B	PBIF	yy

Parameter C of input function of with NIF preloaded input number (value depending on input function, according to value described in chapter 12.13.1 Selection of Input Functions)

Shows present position captured with input
Shows the position captured with input 12
Set all 8 capture Position Register to 0
Activate capture position function over input 12
Break Delay in [ms]
Attention: no works with the SMU module

Parameter C	PCIF	zz
Tell Capture Position	TCP	1-8
Tell Capture Pos. Buffer	TCPB	1-8
Clear Capture Position	CLCP	1-8 (all)
Capture Pos. Input 12	CP12	0,1
Break Delay	BRKD	1-1000 (ms) / ?

12.6.14 Limit Position ELAX®

DESCRIPTION	Short	CMD	PARAMETER
Start calibration of the internal mechanical limit stop positive. After the calibration the value can be read with DMLPP . Position of the detected internal mechanical limit position positive ? = Returns the position of the detected internal mechanical limit stop positive. 0 = Deletes the position of the detected internal mechanical limit stop positive Note: - If DMLPP is deleted (DMLPP = 0), the value for the internal mechanical limit stop for the reference in positive direction is <stroke ELAX + 1mm> - If the value for the internal mechanical limit stop positive is known, this value can be set without calibration (without command MLC).	Mechanical Limit Calibration Detected Mechanical Limit Position Positive	MLC DMLPP	0, <Stroke ELAX> - <Stroke ELAX + 3mm> / ?
Position of the detected external mechanical limit stop position negative. ? = Returns the position of the detected external mechanical limit stop negative. 0 = Deletes the position of the detected external mechanical limit stop negative Note: - MLPP always needs to be chosen smaller than MLPN - If MLPN is deleted (MLPN = 0), the value for the internal mechanical limit stop itself is used for the reference in negative direction, which is <-1mm> as per definition. - The position of an externally mounted mechanical limit has to be accurate. If the entered position of the externally mounted limit stop is wrong, the alignment of the coils to the magnets cannot be completed and the motor won't be capable to drive	Mechanical Limit Position Negative	MLPN	<-3mm> - <stroke ELAX + 3mm> / ?

Position of the detected **external** mechanical limit stop position positive.
 ? = Returns the position of the detected external mechanical limit stop negative.
 0 = Deletes the position of the detected external mechanical limit stop negative.

Mechanical Limit Position **MLPP** <-3mm> - <stroke ELAX + Positive 3mm> / ?


Note:

- MLPP always needs to be chosen bigger than MLPN
- If MLPN is deleted (MLPN = 0), the value for the internal mechanical limit stop itself is used for the reference in negative direction, which is <-1mm> as per definition.
- The position of an externally mounted mechanical limit has to be accurate. If the entered position of the externally mounted limit stop is wrong, the alignment of the coils to the magnets cannot be completed and the motor won't be capable to drive

12.6.15 Force Control

DESCRIPTION	Short	CMD	PARAMETER
<p>Force Calibration is started with distance parameter. Value from 1 to 10'000'000 = Distance in Inc. of the scan run. ? = Returns whether scanned values are available 0 = Force Calibration delete scanned values</p> <p>The Force Calibration works iteratively and improves itself in repeated execution. If the motor oscillates during the Force Calibration, then wrong values are stored and the oscillation increases. In this case, the scanned values must be deleted with FCO before starting a new Force Calibration.</p> <p>In the libraries for the operation with bus module, there exists an input "Iterative FC disable" in the function block JS_MC_ForceCalibration for this case.</p> <p>Important: Force Calibration scan drive will begin at current position</p> <p>Test function to check Force Calibration effect through manual movement of the carriage slider. 2 = Test Force Calibration On (without active compensation) 1 = Test Force Calibration (with active compensation) 0 = Test Force Calibration off (Servo holds position)</p> <p>Request Status of Force Calibration: 0 = No Force Calibration scan values available 1=Force Calibration scan values available</p> <p>Automatic I_Force Drift Compensation Drive in positive direction</p> <p>Automatic I_Force Drift Compensation Drive in negative direction</p> <p>I_Force Drift Compensation Settings, bitwise coded: Bit0: Continuous compensation at disabled power stage Bit1: Automatic compensation before force calibration Bit2: Continuous compensation at enabled power stage at applicable position (see command PIFDC)</p> <p>Position for I_Force Drift Compensation at enabled power stage, depending on the motor type</p> <p>Maximal approved force-proportional current [x10mA] 0 = Deactivated</p> <p>→ As soon as the max. approved current has been hit, info „30“ is being activated and can be retrieved over Process Status registry</p> <p>Bit 15 „I_FORCE_LIMIT_REACHED“ with command TPSR (Refer to chapter 15.1.2 Force Limitation)</p> <p>Change Limit DR_I_FORCE to xx x 10mA value xx will overwrite the current parameter DR_I_Force, until DRIVE I_Force END</p> <p>Driving with limited force until reaching an object or the end position if there is no object. xx= [1-10] No. of the selected Drive I_Force parameter set</p> <p>Force-proportional, actual current-value filtered [mA] (Refer to chapter 15.1.3 Force Monitoring)</p> <p>Actual motor current [mA]</p>	<p>Force Calibration</p> <p>Force Calibration Test</p> <p>Force Calibration Valid</p> <p>I_Force Drift Compensation Positive</p> <p>I_Force Drift Compensation Negative</p> <p>I_Force Drift Compensation Settings</p> <p>Position I_Force Drift Compensation</p> <p>Limit I_Force</p> <p>Change Limit I Force</p> <p>Drive I_Force</p> <p>I Force Actual</p> <p>Tell motor current</p>	<p>FC</p> <p>FCT</p> <p>FCV</p> <p>IFDCP</p> <p>IFDCN</p> <p>IFDCS</p> <p>PIFDC</p> <p>LIF</p> <p>CLIF</p> <p>DIF</p> <p>IFA</p> <p>TMC</p>	<p>0-< stroke LINAX®/ELAX® / ?</p> <p>0,1,2 / ?</p> <p>xx / ?</p> <p>0-7 / ?</p> <p>?</p> <p>0 – value of “I run” / ?</p> <p>xx</p> <p>xx</p>

Select sectors which should be active.
E.g. xx = 100110-> active are the sectors 2,3,6
Binary from right side LSB
(binary notation, LSB = sector 1)
Reads I_FORCE peak value [x1mA]
xx=not defined-> Max peak value over all sectors
xx=n-> peak value of sector n
shows the active sectors which force curve did not correctly
pass through
E.g. xx = 1001->Error in sector 1 and 4.
(binary notation, LSB = sector 1)
Is taking current actual position as an offset for all sectors with
restart of monitoring.
Furthermore the positions „Wait for distance greater/less“ and
„Jump if distance greater/less“ are adjusted by this offset.
Provide offset for all sectors with restart of monitoring.
xx = [Inc] offset
Furthermore the positions „Wait for distance greater/less“ and
„Jump if distance greater/less“ are adjusted by this offset xx.
E.g. xx = 0, sets offset to 0
Selecting sector number for which parameters shall be
changed. xx = [1-10] Sector number, NSEC? = Retrieving the
selected sector number.
Sector start distance.
xx = [Inc] starting distance (current position – sector offset)
Sector end distance.
xx = [Inc] ending distance (current position – sector offset)
Lowest value I_Force in pre-selected sector. xx [x10mA]
Highest value I_Force in pre-selected sector. xx [x10mA]
Definition of transitions **Entry** and **Exit** in sector
xx = activated transition 1,2,3,4 Entry/Exit



Bit 15..12	11..8	7..4	3..0	xx
Entry	not used	Exit	not used	
4 3 2 1	0	4 3 2 1	0	Transition.
0 0 0 1	0 0 0 0	0 0 1 0	0 0 0 0	bin
1	0	2	0	hex
			4128	dec

Selecting Drive I_Force number in which parameters shall be
changed.
xx= Drive I_Force number 1-10. NDIF? =
Retrieving selected sector number
Acceleration for Drive I_Force xx [x1'000 inc/s²]
Speed for Drive I_Force
xx [inc/s]
Limitation of I-Force current while Drive I_Force
xx [x10mA]

Select Sectors **SSEC** xx / ?
I Force Peak **IFPK** xx
Sector I_Force Curve Failed **SIFF** xx / ?
Take Position as Sector Offset **TPSO**
Set Sector Offset **SSO** xx / ?
Number of Sector for change parameter **NSEC** xx / ?
Sector I Force Start **SIFS** xx / ?
Sector I Force End **SIFE** xx / ?
I Force High **IFH** xx / ?
I Force Low **IFL** xx / ?
Sector Transition Configuration Decimal **STC** xx / ?
Sector Transition Configuration Hexadecimal **STCX** xx / ?

Number of Drive I_Force to change parameter **NDIF** xx / ?
Acceleration of selected Drive I_Force **ADIF** xx / ?
Speed of selected Drive I_Force **SDIF** xx / ?
I_Force Limit of selected Drive I_Force **IDIF** xx / ?

Direction Drive I_Force
xx = 0 -> positive, xx = 1 -> negative

Direction of selected Drive **DDIF** xx / ?
I_Force

12.6.16 Correction Table

DESCRIPTION	Short	CMD	PARAMETER
Status of correction table: 0= correction table deactivated 1= correction table activated 2= correction table initialized (physical values = Encoder value)	Correction Table State	CTAB	0-2 / ?
Starting position of the correction table in [inc]	Correction Table Position Start	CTPS	0-500'000'000 / ?
Distance between the entries in the correction table in [inc]	Correction Table Distance Points	CTDP	10-30'000'000 / ?
Preselect absolute encoder position in correction table in [inc]	Correction Table Preselect Position	CTPO	0-2'000'000'000 / ?
Physical position deviation for preselected encoder position in correction table in [inc]	Correction Table Value	CTVA	-30'000-30'000 / ?

12.6.17 System Information

DESCRIPTION	Short	CMD	PARAMETER
Present position $\pm 2 \cdot 10^9$	Tell Position	TP	
Require actual motor velocity [inc/s]	Tell Velocity	TV	
Motor temperature in degree Celsius	Tell Temperature	TT	
Status: 0 = Power OFF, 1 = Power ON, 2 = In motion, 9 = Error	Tell Status	TS	
		New: please use TPSR	
Binary coded process status, size of return string 4 Bytes in HEX format ERROR = BIT 0 HOME = BIT 1 IN_MOTION = BIT 2 IN_POSITION = BIT 3 END_OF_PROGRAM = BIT 4 IN_FORCE = BIT 5 IN_SECTOR = BIT 6 FORCE_IN_SECTOR = BIT 7 INVERTER_VOLTAGE = BIT 8 END_OF_GANTRY_INIT = BIT 9 NEGATIVE_LIMIT_SWITCH = BIT 10 POSITIVE_LIMIT_SWITCH = BIT 11 EMERGENCY_EXIT_1, REMAIN POWER ON = BIT 12 (Function can only be used without bus module. With bus module, apply function "EMERGENCY_EXIT"). EMERGENCY_EXIT, POWER OFF = BIT 13 FORCE_CALIBRATION_ACTIVE = BIT 14 I_FORCE_LIMIT_REACHED = BIT 15 STO PRIMED/HIT = BIT 16 SS1 PRIMED/HIT = BIT 17 SS2 PRIMED = BIT 18 SS2 HIT = BIT 19 SLS PRIMED = BIT 20 SLS SPEED HIT = BIT 21 SLS POSITION HIT = BIT 22 WARNING = BIT 23 INFORMATION = BIT 24 PHASING DONE = BIT 25 I_FORCE_DRIFT_COMPENSATION_DRIVE_ACTIVE = BIT 26	Tell Process Status Register	TPSR	
Actual motor current	Tell motor current	TMC	(mA)
Motion time [milliseconds] of the last profile drive	Tell Motion Time	TMT	
Read process timer [milliseconds] refer also program functions TIMER_START, TIMER_STOP	Tell Process Time	TPT	
Version number of installed firmware	Version	VER	
Version number of installed SMU firmware	Version SMU	VERS	
Versions number of the installed bus module firmware	Version Bus Module	VERB	
Versions queries of the boot loader (from version V4.00)	Version Boot Loader	VERL	
MAC address query of PROFINET / Powerlink / EtherNet/IP bus module	MAC address Bus Module	MACB	
Temperature control, instantaneous value integration	I2T	I2T')	
Temperature control, maximum value integration painter	I2TM	I2TM')	

12.6.18 Bus Module Information

DESCRIPTION	Short	CMD	PARAMETER
Baud rate of the optional CANopen interface	CAN Baud rate	CAB	1'000 - 1'000'000 / ?
Set cycle time [microseconds] in Cyclic Synchronous Position Mode (DS402). Used RMR for interpolation. Only multiple of 100 micro seconds possible	PDO Cycle Time	PCT	100-10'000 /?
Versions number of the installed bus module firmware	Version bus module	VERB	
IP address queries EtherNet/IP modules (from version V4.00)	IP Address bus module	EIPB	
Reset bus module	Reset bus module	RESB	
MAC address query of PROFINET / Powerlink / EtherNet/IP bus module	MAC address bus module	MACB	
Re-adjust Bit „P402 Set Point Acknowledge“ to behavior. equal or smaller than firmware V3.68H	Set Point ACK disable	SPAD	0 - 1

12.6.19 Error Handling

DESCRIPTION	Short	CMD	PARAMETER
Error number 01-99	Tell Error	TE	
Error number description string	Tell Error String	TES	
Retrieving error buffer (last 8 appearing info's, warnings or errors)	Tell Error Buffer	TEB	
Description of the error state from the SMU (Only possible if SMU available)	Tell Error SMU	TESM	
Description of the error state of the SMU at the time of error 89 (Only possible if SMU available)	Tell Error SMU History	TESMH	

12.6.20 System Monitoring

DESCRIPTION	Short	CMD	PARAMETER
Switching off or turning on the encoder plausibility test: 0=Encoder plausibility test on 1= Encoder plausibility test off (for rotary motors only, XENAX® HW >= 4.0)	Encoder Plausibility Checking Disable	ENCPD	0-1 / ?
Watchdog for Serial/Ethernet interface 0 = deactivated 1-60'000 = Watchdog time in [ms]. If output stage is on and no ASCII command was received over the Serial or Ethernet for <WD> ms, output stage is turned off and error code 77 is shown.	Watchdog	WD	0-60'000 ms / ?

12.7 Move Axis by Forceteq®

The Force Calibration function compensates the magnetic cogging forces, the load force and the friction forces of the LINAX®/ELAX® iron-core linear motors and rotary motor axes ROTAX® from Jenny Science.

Refer to chapter 15 Force Process Forceteq®



12.8 Move Axis Motion Diagram

Recording position, acceleration, IForce and position deviation

LOGGING AUTO


Recording starts, as soon as the drive has started. The record lasts until the drive and a possible program have ended.

LOGGING TIME

Recording starts, as soon as the drive has started. The record lasts as long as the time indicated (2-8000ms).

record new

Initialization for new recording sequence. Wait for message "ready for recording next motion". Start motion in command panel (*move axis / by click or by command line*) e.g. G44000.



SPEED


Records speed in increments in relation to the position.

IFORCE

Records current in milliampere in relation to the position.

DEVIATION

Records position deviation in increments.




zoom + / zoom -

Zoom of curve section on time axis.

The middle of the zoom-range can be set with the arrow button on the top. Press key "zoom +" to draw the curve section.


Press key "zoom -" for undo zoom action.

The zoom function also works over the mouse wheel.



Command

Enter command e.g. starting position of the motor, REF, GO, drive on a position or repeat reverse (RR).




load file

Shows a motion profile which was saved on the computer. The upload has no influence on the parameters of the servo controller.

save file

Saves the motion profile on the computer.



12.9 Index

An Index is a motion profile and contains acceleration (ACCEL), speed (SPEED), distance (DISTANCE) and TYPE of distance (*absolute (ABS)*, with reference to the zero position or *relative (REL)* with reference to the present position).

The values always refer to increments of the incremental encoder. The INDICES simplify programming and reduce the communication time by serial control. Execute with IXxx<CR>.

A maximum of 50 INDEXES can be predefined.

EDIT

NEW INDEX = Create new index

CLEAR INDEX = Clear index number

CURRENT INDEX


NR = A list containing all already defined indices

COPY TO = Current Index can be copied into a new Index

PARAMETERS

Setting of the parameters „CURRENT INDEX“

ACCx1000	Acceleration (2-1'000'000'000 x 1'000 Inc/s ²)
SPEED	Speed (10-100'000'000 Inc/s)
DISTANCE	Distance in Inc
TYPE	ABS= Absolut (Position), REL=Relative (WEG)
Teach Pos	Current position is set in the field "DISTANCE"



12.10 Drive I_Force

A DRIVE I_FORCE is driving with force consisting of acceleration (ACCEL), speed (SPEED), current (I_FORCE) and driving direction (DIRECTION).

Up to 10 DRIVE I_FORCE can be stored.

EDIT

NEW DIF = Create new Drive I_Force

CLEAR DIF = Clear Drive I_Force number

CURRENT DIF

NR = A list containing all already defined Drive I_Force
COPY TO = Current DIF can be copied into a new Drive I_Force

PARAMETERS


Setting of the parameters „CURRENT DIF“

ACCx1000

SPEED

DR_I_FORCE

DIRECTION



Acceleration ($2 \cdot 10^{10} \text{ Inc/s}^2$)

Speed ($10 \cdot 10^6 \text{ Inc/s}$)

Force Limitation ($0 \cdot 10^8 \text{ x10 mA}$)

POS = Positive direction, NEG = Negative direction

12.11 Sector I_Force


In the WebMotion® program menu „sector I-force“ up to 10 different force sectors can be defined.

Example:

Once an object is touched the force progression shall be examined in a sector of 150 to 170 Increments.

When entering the force sector (“ENTRY”) the force should be between 3 and 4N. When exiting the sector (“EXIT”), the force should have reached 4N. These force specifications are defined with the in the force sector incoming and exiting sector boundaries.

Refer more Information in chapter 15 Force Process Forceteq®



12.12 Program

Please also consult the TUTORIAL Video
**JSC Tutorial 5: Programming of a Pick and Place
 System with XENAX® Master-Slave** on our website, in
 which you can follow a practical example.

Here you can define program sequences line by line.

PROGRAM

Select, create, copy or delete a program.

LINES

In this list all defined program lines of the present program will be shown. The arrows at the top and below serve for scrolling within the window. If a line in the list is selected then it can be moved with MOVE arrow.

Maximum number of lines depends on program mapping (PMAP, default = 0):

PMAP = 0	Prog 1-15: 50 lines	Prog 16-63: 10 lines
PMAP = 1	Prog 1-5: 130 lines	Prog 6-63: 10 lines


EDIT LINE

This is where program lines can be edited.

SET = sets the edited line in the LINES list.

INSERT = Edited lines can be inserted at any position by selecting the according location in the LINES content.

CLEAR = lines can be deleted by selecting the according line in the list.



12.12.1 Program commands

Description	Command	Parameter	Master / Slave
Reference for LINAX®/ELAX® / ROTAX® and third party motors	REFERENCE		MS
Execute index number xx or change according operation yy with distance zz Operation „EXE“: Drive index No. xx and start a new index after COMPLETION zz% of the actual index command ACTION „=“: Set index distance to zz ACTION „+“: Increase Index distance by zz ACTION „-“: Reduce Index distance by zz ACTION „POS“: Set Index distance to the slider actual position.	INDEX	xx, yy, zz	MS
Set Output number xx	SET OUTPUT	xx	MS
Clear Output number xx	CLEAR OUTPUT	xx	MS
Go to Line number xx	GOTO LINE	xx	
Go to line number xx, if input number yy active	GOTO LINE IF INPUT	xx, yy	
Set Loop Counter # to xxxx (1-10000)	SET LOOP COUNTER (A-E)	xxxx	
Decrement Loop Counter #, if not zero, jump line xx. Loop counters can be interleaved with each other	DEC LOOP COUNT (A-E) JNZ LINE	xx	
Wait xx ms	WAIT TIME (ms)	xx	
Wait for logical High of Input number xx within timeout frame yy, otherwise jump to line zz „error handling“ (timeout can only be used locally, not for (remote)	WAIT INPUT NR HIGH	xx	MS
Wait to logical Low of Input number xx within timeout frame yy, otherwise jump to line zz „error handling“ (timeout can only be used locally, not for remote)	WAIT INPUT NR LOW	xx	MS
Set position counter to 0, (not possible with LINAX®/ELAX®, with ROTAX® only possible if it is not referenced)	CLEAR POSITION		
Execute Profile number xx	PROFILE	xx	MS
Start process timer	TIMER START		
Stop process timer	TIMER STOP		
Command TPT (Tell Process Timer) returns measured time in milliseconds			
LINAX®/ELAX® drives to mechanical limited position, refer <i>setup / reference</i> .	REF LIMIT STOP		
Executing Force Calibration, Start Pos xx, End Pos yy	FORCE CALIBRATION	xx, yy	
Automatic I_Force Drift Compensation drive xx = POS => drive in positive direction xx = NEG => drive in negative direction	I_FORCE DRIFT COMPENSATION	xx	
Execute DRIVE I_FORCE No. xx	DRIVE I_FORCE	xx	
Selection of active sectors with Bit mask. E.g. xx = 1010 → sectors 2 and 4 are active. LSB is on right.	SELECT SECTORS	xx	
Wait until Limit I_FORCE is reached according parameter DRIVE I_FORCE within timeout xx, otherwise jump to line yy „error handling“	WAIT LIMIT I_FORCE	xx, yy	
Wait for distance (absolute position – Sector Offset) to be greater than xx within timeout frame yy, otherwise jump to line zz „error handling“	WAIT FOR DISTANCE GREATER	xx, yy, zz	

Wait for distance (absolute position – Sector Offset) to be smaller than xx within timeout frame yy, otherwise jump to line zz „error handling“	WAIT FOR DISTANCE LESS	xx, yy, zz	
Wait for process status register Bit xx High within timeout frame yy, otherwise jump to line zz „error handling“	WAIT PROCESS STATUS BIT HIGH	xx, yy, zz	
Wait for process status register Bit xx Low within timeout frame yy, otherwise jump to line zz „error handling“	WAIT PROCESS STATUS BIT LOW	xx, yy, zz	
Is taking the actual position as offset value for all sectors followed by the restart of monitoring. Furthermore the positions “Wait for distance greater/less” and “Jump if distance greater/less” are being adjusted by the offset as well. Setting offsets for all sectors followed by the restart of monitoring. xx = [Inc] Offset Furthermore the positions “Wait for distance greater/less” and “Jump if distance greater/less” are being adjusted by the offset xx as well. e.g. xx = 0, sets offset incl. TAKE POS AS SECTOR OFFSET to 0 Changing Limit DR_I_FORCE to xx x 10mA Value of I_FORCE will overwrite the current parameter I_Force in DRIVE I_FORCE until DRIVE I_FORCE END Jump to line zz if distance xx (absolute position – sector offset) greater than xx e.g. driving distance was too big after force was reached Jump to line zz if distance (absolute position – sector offset) smaller than xx e.g. driving distance was too small after force was reached Jump to line xx “error handling” if one or more sectors are not passed correctly. Only active sectors are being tested. Caution: Before this analysis can be done, “DRIVE I_FORCE END” has to be completed. Stop Drive I_Force, current position = set point position, parameter LIMIT DR_I_FORCE inactive Power stage turned off, the linear motor can be moves by hand. Power continues (>PWC) Turning on the power stage while using the most recent absolute position and without the need of referencing the linear motor, e.g. after error 50 or after “Power Quit” . This is only possible as long as the logic supply has not been interrupted after the linear motor was referenced. Program is being ended and does not proceed to last line. Beneficiary for „error handling“	TAKE POS AS SECTOR OFFSET		
	SET SECTOR OFFSET	xx	
	CHANGE LIMIT I_FORCE	xx	
	JUMP IF DISTANCE GREATER	xx, zz	
	JUMP IF DISTANCE LESS	xx, zz	
	JUMP IF I_FORCE SECTORS FAULT	xx	
	DRIVE I_FORCE END		
	POWER QUIT		MS
	POWER CONTINUE		MS
	PROGRAM END		

Important Note:

All entries in menu application / *program* must be “saved” in order to be activated (Please also refer to chapter 12.22 Save.

MS: Master/Slave function can be started on another controller.

LOC = Local, ID1...4 = Device with according Card Identifier (CI)

The command set for the XENAX® force processes are explained in chapter 15 Force Process Forceteq®.

Example: Initialization LINAX®/ELAX®

This example shows the initialization of a LINAX®/ELAX® linear motor with the command REFERENCE which then drives to a defined starting position (INDEX 1).

The start position is free to choose as long as it is within the stroke of the motor. In this example the axis drives to start position 0.

Important:

The command REFERENCE has to be completed once after powering on the servo controller. Only after reference, other motion commands are possible.

The screenshot shows the 'PROGRAM' menu with the following settings:

- PROGRAM: NEW
- NUMBER: 1
- COPY TO: --
- CLEAR: --

The 'LINES' list contains:

- 1 REFERENCE
- 2 EXECUTE INDEX 1

The 'EDIT LINE' field shows '3'.

The 'EDIT' panel on the right shows the following parameters:

- NEW INDEX: --
- CLEAR INDEX: --
- CURRENT INDEX: NR 1
- COPY TO: --
- PARAMETERS:
 - ACC x1000: 2000
 - SPEED: 80000
 - DISTANCE: 0
 - TYPE: ABS

Example: Initialization ROTAX® or third party motors

The reference function for rotary motors can be defined in the menu *setup / reference* (refer chapter 12.18.3 Reference ROTAX® und Third Party Motors).

With this function the motor drives first to a reference switch (approx. zero) and then to the encoder Z-mark.

If reference position differs from starting position, an index (INDEX 1) can be executed to move to start position.

The program starts with the ASCII command “PG1” in the menu *move axis / by command line* or by activating an input function “PG1”.

The screenshot shows the 'PROGRAM' menu with the following settings:

- PROGRAM: NEW
- NUMBER: 1
- COPY TO: --
- CLEAR: --

The 'LINES' list contains:

- 1 REFERENCE
- 2 EXECUTE INDEX 1

The 'EDIT LINE' field shows '3'.

The 'EDIT' panel on the right shows the following parameters:

- REF DIRECTION: CW
- REF SPEED: 50-25000 50
- REF INPUT: 1
- Z-MARK DIR: CCW
- Z-MARK SPEED: 50-10000 50
- CLEAR OUTPUTS: NO

12.13 I/O Functions

OUTPUT FUNCTIONS

Assigning output functions to a physical output.
ON und OFF of the outputs by mouse click.

INPUT FUNCTIONS

Assigning input functions to a physical input.
Choice of high- or low-activity of all inputs.
Input 9-12 binary coded.

In the operations overview, the physical input and output conditions are displayed.



12.13.1 Selection of Input Functions

LINAX®: Reference for LINAX®, travels the distance of two coded reference marks and calculates the absolute position according LINAX® linear motor.	REF	
ELAX®: Reference for ELAX®, the absolute position is determined by driving to a mechanical limit.		
ROTAX® and third party motors: Complete Reference according to REFERENCE for ROTAX® and third party motors...		
Execute index number xx or change according operation yy with distance zz	IX	xx, yy, zz
Execute Program xx	PG	xx
Set output xx	SO	xx
Clear output xx	CO	xx
Drive (Jog) positive (const. speed xxxxx inc/sec) while input # is active	JP	xxxxx
Drive (Jog) negative (const. speed xxxxx inc/sec) while input # is active	JN	xxxxx
Capture Position, on triggered edge at input	CPOS	
Interrupt program, while Input active	IP	
Stop Impulse, edge triggered*)	SI	
Stop Impulse Counter, like SI but does not set position counter to 0*)	SIC	
Limit-switch negative*)	LS-	
Limit-switch positive*)	LS+	
Emergency Exit with power off*)	EE	
Emergency Exit with power on, Position stop (<i>Function can only be used without bus module. With bus module, apply function "EE"</i>)	EE1	
Power ON continue, keep encoder counter	PWC	
Execute profile nr. xx	PRF	xx
Reference Limit Stop, also refer menu <i>setup / reference</i>	RSTO	
Speed and acceleration will be reduced by xx percent	OVRD	xx
Stops and quits active program	PGEX	
Drive I_Force No. xx	DIF	xx
Power stage turned off, the linear motor can be moved by hand.	PQ	

*) Stop with ED

(Emergency Deceleration) braking ramp

Notes to Input Functions:

Except EE, EE1 all input functions must only be parameterized in a Pick & Place Maser or Gantry Master.

For rapid deceleration in emergency shut down situations (LL, LR, EE, EE1, SI, SIC, LS-, LS+) the special ED (Emergency Deceleration) can be given a value (COMMAND > ED xxxxx).

The Emergency Exit functions have the highest priority and are always activated immediately. As long as EE is active no other function can be executed.

For the other functions the following applies: If another function is already active it has to be finished before the next one is started. If several function calls are current at the same time, then the one with the lowest input number is executed first.

To run a program endlessly the assigned input can be simply left active.

With Interrupt program (IP) the program being executed can be interrupted. If IP becomes inactive the interrupted program will be continued directly.

With stop impulse (SIC) the running movement is stopped and aborted.

A new travel command can then be executed even with unreleased stop impulse (SIC active).

12.13.2 Selection Output Functions

REF has been completed	REF
In motion, motor is running	INMO
End of program	EDPG
Trigger (5ms, defined by TGU, TGD commands)	TGR
Error pending	ERR
Release brake	BRK
In position, within deviation target position (DTP)	INPO
Limit I_Force reached (command LIF)	IFML
I Force In Sector, when motion is completed	IFSE
In Sector (during and after motion is completed)	INSE
In Force (during and after motion is completed)	INFO
Warning pending	WARN
Information pending	INFM
STO Feedback 1	STO1*
STO Feedback 2	STO2*
SS1 Feedback 1	SS11*
SS1 Feedback 2	SS12*
SS2 Feedback 1	SS21*
SS2 Feedback 2	SS22*
SLS Feedback 1	SLS1*
SLS Feedback 2	SLS2*


* Feedbacks are status information and not SMU safety functions. Only possible with optional SMU (Safety Motion Unit).

12.13.3 Operation with Additional Holding Brake

An additional holding brake for LINAX® Lxs and Lxu Motor types can be controlled with a XENAX® servo controller. The output function BRK (Brake) can be assigned to one of the controller outputs and used in combination with the BRKD (Brake delay) parameter.

This function allows the activation of a time delay by turning off the power stage. First the brake control signal output is set to low (brake is active) and after BRKD milliseconds (setting range from 1 to 1000ms) the power stage is turned off.

This feature allows an active braking with a switched-on power stage and after this a controlled power stage turn off, when the brake is safely on. The time delay is only effective by turning off the power stage.



12.14 Profile (Velocity)

Complex motion profiles can be linked with up to seven profile segments.

The XENAX® servo controller is able to store up to five profiles.

The profile definition includes a start position as well as absolute end-position, end-speed and acceleration of each profile segment. The result of these indications is the segment type (Speed up, Slow down, constant speed).

The “Profile Check” tests if the entered values can be realized with the connected linear motor.

Before profile curve starts, the linear motor has to be located at the predefined start position.



EDIT

NEW PROFILE = Enter new profile

CLR PROFILE = Clear profile

CURRENT PROFILE

This list contains all predefined profiles.

PARAMETERS

Set up of the parameters in „CURRENT PROFILE“

S-CURVE

Percentage S-curve rounding of the profile. Automatic calculation of jerk parameter for each profile segment.

POSITION

First panel: Input absolute start position

POSITION

End position of corresponding profile segment

SPEED

End speed of corresponding profile segment

ACCx1000

Acceleration within profile segment

PROFILE CHECK

The parameters will be checked on drivability (is distance long enough for demanded speed and acceleration ?)

Correct profile segments are colored in green, wrong segments are red and untested segments are orange


Defined and tested profiles have to be stored in the servo controller under „save“.

A profile can be started with the command PRFx. X represents the profile number.

Profiles can also be started as input function or in a program.

12.15 Captured Pos

The XENAX® servo controller has two special functions to read the current position of the motor.




Record function of the actual position controlled by Input

In the WebMotion® menu I/O, you can select the record function CPOS for all digital inputs 1-8.

Reaction time > 4 ms.

(Input 1 = Pos Input 1 etc.)

ASCII command: TCPn (n = register number)




Record function of the actual position controlled by edge

With each increasing edge at input 12, the current position of the motor is written in a buffer register (Start is Captured Pos 1).

Reaction time ~ 4-6µs.

(First edge position = Captured Pos 1 etc.)

ASCII command: TCPn (n = register number)



Function is available over Jenny Science bus module in asynchronous operation, too.

Object	Sub Idx	
5000h	0x5010	CLCP Clear all Captured Position
	0x5015	Captured Position Mode Input 12
	0x5016	Captured Position Mode Input 1..8
5003h	0x37	Read Buffer Position (1..8)
	0x38	Return of value

ASCII
CLCP
CP120
CP121

TCPn (n=1..8)

12.16 State Controller

The closed loop control system consists of a state controller with observer.

Basic Settings

These settings consent a very easy and clearly arranged controller configuration for most common applications.

Basic PAYLOAD

Additional payload on the linear motor in g. The weight of the motor carriage slider is automatically taken into consideration with the motor identification.

Or



Basic INERTIA (only for ROTAX® and Third Party Motors)

Adjustment of the external torque of inertia.

If a gear box is placed between the motor and the load, you must adjust the external torque of inertia according to the motor shaft. The gear transmission ration needs to be squared.

e.g. With a gear transmission ratio of 20:1, we need to reduce the external torque of inertia by a factor of 400.

For direct drive linear motors, it is important to set the parameter for the moment of inertia of the external payload (INERTIA), otherwise the linear motor oscillates. Because there is a factor of 10⁻⁹, there can be very large values. If so, please enter the parameter in the corresponding field.

Calculation Example: The external payload is a homogenous disc of 1.1kg and Ø200mm.

Formula is as following:

$$J = \frac{1}{2} m \cdot r^2 = 5.5 \cdot 10^{-3} \text{ kgm}^2$$

scaling factor with 10⁹ results in a parameter value of 5'500'000.

(Please refer to XENAX® Servocontroller/General files for XENAX® Xvi/PARAMETERIZATION OF ROTATIVE.zip on <https://www.jennyscience.ch/en/products/download.>)

Basic GAIN POS

Gain of position controller. This parameter must be reduced when payload is increased.

The "Auto Gain" function automatically proposes a value

Auto Gain



Sets the gain of position controller based on the entered payload value.

This is a theoretically calculated value. A small adjustment might be necessary and can be completed with "GAIN POS".

Noise GAIN CUR

Gain of current controller. The reduction of this gain consents a diminution of noise emissions in case of sound-sensitive environments.

Deviation POS ACT

Maximum position deviation in encoder increments. If this value is exceeded, the error 50 occurs and flashes on the 7-segment display.

Deviation TARGET

Permissible position deviation in the target point until the status "in position" comes up.

Default

Standard setting of the different parameters. All parameters can be manually modified during the controller tuning and can be reset to default values with the „Default“ button.

Advanced

Switch to advanced controller configuration parameters

Advanced Settings

These settings permit an advanced controller tuning for complexes constructions affected by mechanical vibrations.

Stability STAB – DYN

This parameter is set per default at 0 and consents to set the controller stability against external disturbances.

Settings in positive direction can improve the dynamic response of the system for basic mechanical construction with small payloads.

Settings in negative direction can reduce the sensitivity of the system to mechanical vibrations.



Avoid vibration FREQ

Current filter frequency. The filter is best suited for the reduction of vibrations with well pronounced frequencies. Typical values are in between 300-500Hz. At a value of 0, the filter is not active. The frequency can be automatically detected with an internal scan function (refer to chapter 12.16.1 F Setting) [or eventually with the help of](#) a smartphone app.

There are 2 types of filters available "active" and "notch" which can be active on different frequencies.

The "active" is to be preferred, as it has little influence on the control loop performance. For resonance frequencies with a wide spectrum, a "notch" filter should be used.

Swing out reduction

This feature permits an automatic modification of the target trajectory, so that the settling time after a finished move can be reduced.

For this swing out reduction, two parameters have to be identified and set:

damping and frequency of the oscillation.

Setting one of the two parameters at 0 disables this feature.

Important Note:

The calculation of the target trajectory can not be abruptly changed in motion. After setting a new value for frequency or damping the axis should remain at standstill at least for 1000ms, before so that the new set of parameters will be inconsistent. (refer to Info 27 in chapter 17 Error Handling).

Attention:

In the case of cyclic interpolated target position operation with a superordinate PLC, the internal controller desired trajectory is modified and the original target position will be reached with some time delay. The correct reaching of the target position must be ensured, tracking the actual position value, prior to start a new motion.

Swing out reduction DAMPING

This parameter consents to set the damping of the mechanical swing out oscillation in % and depends on the load.

Swing out reduction FREQ

This parameter permits to set the frequency of the mechanical swing out oscillation with a resolution of 0.1Hz. These oscillations exhibit low frequencies (usually below 30Hz).

The slowest possible frequency to be set is 2Hz.

This frequency can be extracted for the “DEVIATION” curve in “Motion Diagram” (refer to chapter 12.8 Move Axis Motion Diagram) if the ratio between load and slider load is sufficiently high.

If this is not the case, this frequency can be determined with the help of a highspeed camera, an acceleration sensor or a smartphone app for vibration measurements.

Basic


Switch to the basic controller configuration parameters.

12.16.1 F Setting


The band width of the position control (GAIN POS) should be set as high as the movements can be completed within the tolerable position deviation but before the motor begins to oscillate. In some applications, usually with high payloads, it sometimes happens that no setting can be found that meets both criteria. If the motor with a set band width begins to oscillate because of a resonance in the system, this oscillation can possibly be suppressed with a filter.

In the menu „state controller“ in WebMotion® the correct PAYLOAD and the required GAIN POS have to be set. If the motor oscillates, the resonance frequency can be found and suppressed with the frequency analysis function.

With the button „Scan>“, the frequency analysis pops up.



When operating, the frequency analysis can be started anytime. But because the current of the motor is being analyzed for the frequency analysis the, the output stage must be turned on. As soon as the analysis is completed, the measuring results are shown in WebMotion® and the frequency can be set.



Settings for the Frequency Analysis

Recordable Time:

The longer the recording time is, the higher is the frequency resolution, but the smaller is the measurable frequency range. For each recordable time, the according measurable frequency range will be shown. Please begin with the minimal recording time of 0.4s (with the maximal frequency range). For


low resonance frequencies, the analysis can be repeated with higher recording time and reduced frequency range.

0.4s	0 - 5000 Hz
0.4s	0 - 2500 Hz
0.8s	0 - 1250 Hz
1.6s	0 - 625 Hz
3.2s	

Go while F Analysis

Turned off:

During the frequency analysis there is no movement of the axis. Please select this option, when the analysis should be completed in halt mode or when there is already a movement active (e.g. through a running program or through a superior PLC).




Turned on:

During the frequency analysis, the axis moves to the indicated position within the selected recording time.


F Analysis

Starts the frequency analysis (and the movement if „Go while F Analysis“ is turned on).



F Setting


If the cursor is located in the adjustable filter frequency range (Notch: 160...2000Hz, Active: 200...2000Hz), the filter frequency can be set according to the frequency the cursor shows by clicking the button „F Setting“. Directly after the frequency analysis, the cursor is automatically located on the frequency with the maximal amplitude within the adjustable filter frequency range. It is likely that this is where the resonance frequency is. However, the cursor can be moved anytime to set another filter frequency.



If the filter shall be turned off, the cursor has to be set to the frequency of 0 and then the button „F Setting“ has to be pushed.

Process of a Frequency Analysis:

This process shows a typical process of a frequency analysis:



Notes to frequency analysis:

- The filter frequency might not always be able to clear the oscillation. Especially when the resonance frequency is low, the controller can possibly be affected too much by the filter frequency and the oscillation won't disappear. In this case please reduce GAIN POS until the oscillation disappears.
- If there are multiple resonance frequencies, try to put the filter frequency in the approximate middle of the resonance frequency.
- On frequency 0, the mean current will be displayed during the frequency analysis. It corresponds to the DC-portion of the motor current, which is rarely 0.

Diagram Amplitude

In this diagram, the amplitudes of all existing frequencies in the motor current are shown. The amplitude and the frequency of the cursor position are displayed on the left side of the diagram.





Diagram I-Motor

This diagram displays the motor current for the frequency analysis. The motor current and the recording time at the cursor position are displayed on the left side of the diagram. Furthermore the same legend shows the position the linear motor slide was located, at the time of the recording.



12.17 Motor

12.17.1 Motors LINAX® and ELAX®

MOTOR TYPE

The connected motor type of LINAX® and ELAX® series will be recognized and shown automatically.

I STOP

Continuous current limitation in standstill.

I RUN

Continuous current limitation while moving.

POLE PAIRS

LINAX® Lx and ELAX® Ex linear motor pole pairs = 1

INC PER REVOL

Number of encoder increments per revolution.

Linear motor axis:

Lxc 44F04, INC PER REVOL = 12'000

other LINAX® products Lxc, Lxe, Lxu, Lxs,

INC PER REVOL = 24'000

ELAX®, INC PER REVOL = 14'171

PHASE DIR


Direction of phase control

U, V, W or V, W, U, depending on motor type.

LINAX® / ELAX® linear motor, PHASE DIR = 0

PHASE OFFSET

Correction of electrical angle, in accordance with the orientation of the coil to the magnet. Value for all LINAX® and ELAX® products and the most of rotary motors PHASE OFFSET = 0



12.17.2 Motor ROTAX®

MOTOR TYPE

The connected motor type of ROTAX® series will be recognized and shown automatically.

I STOP

Continuous current limitation in standstill.

I RUN

Continuous current limitation while moving.

POLE PAIRS

Number of pole pairs of AC / DC / EC brushless servo motors. For DC brush-type servo motors, set POLE PAIRS to 0.

INC PER REVOL

Number of encoder increments per revolution by AC / DC / EC brushless servo motors. Not used for DC brush-type servo motors.

PHASE DIR

Direction of phase control

U, V, W or V, W, U, depending on motor type. Can be detected with command PHDD.

With DC brush-type servo motors:

PHASE DIR = 0, if motor shaft turns clockwise with direct DC-supply voltage.

PHASE DIR = 1, if motor shaft turns counter clockwise with direct DC-supply voltage.

PHASE OFFSET

Correction of electrical angle, in accordance with the orientation of the coil to the magnet. Value for the most of rotary motors PHASE OFFSET = 0

ROTOR INERTIA

Rotor moment of inertia of the motor, with factor 10^9 .

TORQUE CONST

Torque constant of the motor, with factor 10^6 .

INDUCTANCE

Phase to phase inductance of the motor.

RESISTANCE

Phase to phase resistance of the motor.



12.17.3 Third Party Motors

THIRD PARTY MOTOR

Motors that are sold by Jenny Science, are available in the database and can be selected.

For parameterization of rotary servo motors, refer to the document XENAX® Servocontroller/General files for XENAX® Xvi/PARAMETERIZATION OF ROTATIVE.zip on <https://www.jennyscience.ch/en/products/download>.

I NOM (FOR I2T)

Acceptable thermic continuous current. Used for I²T monitoring and current limitation in standstill.

I PEAK

Continuous current limitation while moving.

NUMBER POLE PAIRS

Number of pole pairs of AC / DC / EC brushless servo motors. For DC brush-type servo motors, set POLE PAIRS to 0.

INC PER REVOLUTION

Number of encoder increments per revolution by AC / DC / EC brushless servo motors. Not used for DC brush-type servo motors.

PHASE DIRECTION

Direction of phase control

U, V, W or V, W, U, depending on motor type. Can be detected with command PHDD.

With DC brush-type servo motors:

PHASE DIR = 0, if motor shaft turns clockwise with direct DC-supply voltage.

PHASE DIR = 1, if motor shaft turns counter clockwise with direct DC-supply voltage.

PHASE OFFSET

Correction of electrical angle, in accordance with the orientation of the coil to the magnet. Value for the most of rotary motors PHASE OFFSET = 0

ROTOR INERTIA

Rotor moment of inertia of the motor, with factor 10⁹.

TORQUE CONST


Torque constant of the motor, with factor 10⁶.

INDUCTANCE

Phase to phase inductance of the motor.

RESISTANCE

Phase to phase resistance of the motor.



12.17.4 Position Overflow

For ROTAX® servo motor types and Third Party Rotative Motors, which are operated e. g. as rotary tables always in the same direction of rotation, it can occur that the encoder position reaches very high positive or negative values

In order to ensure that the position can be continuously incremented in positive or negative direction, a controlled overflow mechanism is integrated in XENAX® servo controller.

The maximum position values correspond to $2^{31}-1 = 2'147'483'647$ inc in positive direction and $-2^{31} = -2'147'483'648$ inc in negative direction. The overflow takes place between these two values.

$2'147'483'647 <> -2'147'483'648$

Example: positive overflow


Actual Position: $2'147'483'646$ inc
Relative Motion: 10 inc

Motion:

Start position: $2'147'483'646$ inc
 $2'147'483'647$ inc
 $-2'147'483'648$ inc
 $-2'147'483'647$ inc

...

Target position: $-2'147'483'640$ inc



Example: negative overflow


Actual Position: $-2'147'483'648$ inc
Relative Motion: -20 inc

Motion:

Start position: **$-2'147'483'648$ inc**
 $2'147'483'647$ inc

...

Target position: $2'147'483'629$ inc




12.18 Reference

12.18.1 Reference LINAX®

12.18.1.1 Reference Absolute, According Reference Marks

REFERENCE Selection

Default, reference over two reference marks on the measuring scale with calculation of the absolute position. This position refers to the mechanical zero point of the LINAX® linear motor axes.



DIRECTION

Enter start direction of the reference travel direction:

POSITIVE (DEFAULT) = Reference direction up. Away, from absolute zero point, in positive direction.


NEGATIVE = Reference direction down, direction towards absolute zero point.

GANTRY => POS = Motors in same direction up, in positive direction (away from zero point).

GANTRY => NEG = Motors in same direction, negative direction (towards zero point).

GANTRY<=>POS = Motors in opposite direction up.

GANTRY<=>NEG = Motors in opposite direction down.



12.18.2 Reference ELAX®

ELAX® does not possess Z-marks on the measuring scale.

The absolute position is determined by driving on a mechanical limit. The direction of the reference can be positive or negative (refer to ASCII command "DRHR")

12.18.2.1 Reference with Internal Limit

If there are no externally mounted limit stops („**MLPN**“ = 0 and „**MLPP**“ = 0), the reference will be completed by the internal mechanical limits of ELAX® itself.

ASCII command „**MLPN**“= Mechanical Limit Position Negative
ASCII command „**MLPP**“= Mechanical Limit Position Positive


Negative Reference (DRHR = 1)

The slide drives in negative direction until the mechanical limit is recognized. This position will then be set to <-1mm> as per definition. In order to complete the reference, the slide moves then to the absolute position 0.

ASCII command „**DRHR**“= Direction REF

Positive Reference (DRHR = 0)

The slide drives in positive direction until the mechanical limit is recognized. If the calibration of the internal mechanical limit was completed (MLC, Mechanical Limit Calibration) positively, the current position is set to the value „**DMLPP**“. If no calibration of the internal mechanical limit was completed positively („**DMLPP**“ = 0), the current position is set to <stroke ELAX + 1mm> as per definition. In order to complete the reference, the slide moves then to the absolute position <stroke ELAX + 1mm>.



12.18.2.2 Reference with External Limit

If there are externally mounted limit stops (**MLPN** ≠ 0 or **MLPP** ≠ 0), the reference (REF) will be completed to one of the externally mounted limit stops.

ASCII command „**MLPN**“= Mechanical Limit Position Negative
ASCII command „**MLPP**“= Mechanical Limit Position Positive

Negative Reference


The slide drives in negative direction until the mechanical limit is recognized. This position will then be set to the value of „**MLPN**“. In order to complete the reference, the slide drives to the absolute position <MLPN + 1mm>.

Positive Reference

The slide drives in positive direction until the mechanical limit is recognized. This position will then be set to the value of „**MLPP**“. In order to complete the reference, the slide drives to the absolute position <MLPP - 1mm>.

Important Note:

The position of an externally mounted mechanical limit has to be accurate. If the entered position of the externally mounted limit stop is wrong, the alignment of the coils to the magnets cannot be completed and the motor won't be capable to drive. If the ELAX® slide is driven to the internal negative limit position, the slide is positioned at <-1mm> as per definition. The position of an externally mounted limit stop has to be indicated in relation to <-1mm>



12.18.3 Reference ROTAX® und Third Party Motors

For ROTAX® and third party motors only, for LINAX® or ELAX® please use directly command „>REF“.

CLOCKWISE = clockwise

COUNTER CLOCKWISE = counter clockwise

REF DIR

Defines start direction for searching the external REF sensors 1 = CLOCKWISE, 2 = COUNTER CLOCKWISE

REF SPEED

Defines speed to search the external REF sensor.

If no home sensor exists, then set this value to 0.

REF INPUT

REF sensor external, input number (NONE or 1-8).

Z-MARK DIR

Defines start direction for searching the Z-mark on encoder 1 = CLOCKWISE, 2 = COUNTERCLOCKWISE.

Or 3 = ON SHORTEST WAY (shortest way, only possible at ROTAX® Rxvp).

Z-MARK SPEED

Speed to search the Z-mark. If no Z mark (Reference mark) exists, then set this value to 0.

CLEAR OUPTPUTS




Set all outputs to OFF after reference.

Note for ROTAX® Rxhq:

Due to the absolute position, the ROTAX® Rxhq is immediately ready for operation after power-on, no reference drive is necessary.

For this purpose, the Z-MARK DIR must be set to 0 and the REF INPUT to NONE.

The position of the encoder immediately after startup always has a value between 0 and 119'999Inc. E.g. in case of a mechanical stop the movable range of the encoder changes depending on the range (between 0 and mechanical stop in positive direction or between 0 and mechanical stop in negative direction) in which the motor is starting up.



12.18.4 Reference to Mechanical Stop

Selection REFERENCE LIMIT STOP

After the ordinary reference of a LINAX® or ELAX®, it is possible drive to a mechanical stop.

Important: This function is optional and has no influence to the absolute positioning counter.

CREEP DIR

UP (Travel direction positive)

DOWN (Travel direction negative)

CREEP SPEED

Speed to mechanical stop [INC/s].

CURRENT LIMIT

Nominal motor current [x10mA] during reference

Power F = motor current x force constant

REF WINDOW


Maximal allowed variation compared to last REF position [INC].

REF WINDOW = 0, testing off
Output Function REF = 1

REF WINDOW = 1, testing on

Variations within allowed tolerance (REF Window):
Output function REF = 1, current REF position will be new reference position.


Variations out of allowed tolerance:
Output function REF = 0,
The subsequent reference will be the new reference position.



12.18.5 Correction Table for LINAX® / ELAX®

Depending on the application's construction in which a LINAX® or ELAX® linear motor axis is used, it is possible that the encoder position does not correspond to the actual physical position of the linear motor slide (e.g. in cross table or for high cantilevered applications with leverage effect).

To a certain degree, the XENAX® servo controller offers the possibility to correlate the encoder position with the actual position. The correction table in WebMotion® offers 51 entries in which the physical position can be entered in fixed distances to the encoder position. The physical position can be measured with an interferometer.



The range for the way can be freely selected. Furthermore, the starting point and the distances between the entries of the table can be defined. If for example the range 0-100'000 increments shall be corrected, the starting position is 0inc and the distance for the 50 remaining table entries is 2'000 inc (100'000 / 50).

The correction values for the table are determined as follows: If the correction table is deactivated, all positions that were entered in the table are being driven to (example above: 0inc, 2'000inc, 4'000inc, ..., 100'000inc). At each position, the actual physical position has to be measured and entered in the correction table. When activating the correction table, all driving commands refer to the actual physical position and no longer to the encoder position of the LINAX® or ELAX® linear motor axes.

Limitations

- Correction table is not supported in case of rotary motors
- Correction table is not supported with communication over Real time Bus module (for example EtherCAT)
- This correction table runs with following commands and functions only: >G, >GP, >GW, >IX, >PRF, >RR, >RW, >TP

Input the correction values with WebMotion®:

With the navigation **setup/reference** in case of
LINAX® or ELAX®

ENC [inc]	PHYSICAL [inc]
0	0
2000	2003
4000	4006
6000	6008
8000	8011
10000	10000
12000	12000
14000	14000
16000	16000
18000	18000

- INIT** Initialize correction table, physical position value = encoder value
- OFF** Correction not active, moving commands refer to encoder position value
- ON** Correction table active, moving commands refer to physical position value
- POS START** Startposition of correction table.
- DIST POINTS** Distance between data entries in correction table
- Physical absolute Position, measured with laser interferometer.
If you enter a G8000 by command, and the laser interferometer reads the physical position 8011, you can put it in the table and press ENTER to take it over to the table.

Encoder Position (automatically generated from POS SSTART and DIS POINTS)

Notes to correction table:

- For the positions outside of the correction table, the correction of the first respectively the last entry in the correction table holds valid. For example the last entry is „ENC:100'000 -> PHYSICAL 100'017“, so for the encoder position of 110'000 the physical value of 110'017 is considered.
- The position values between the table entries are interpolated.
- The correction table is saved in the application data of the XENAX® servo controller.
- After a reset of the XENAX® servo controller (command “RES”), the correction table will be initialized and deactivated (physical position = encoder position).
- During the measurement of the physical position values, the correction table has to be deactivated.

ASCII Commands

>RES (Reset XENAX®) the correction table status is OFF, encoder values = physical values

>CTAB 0 (= OFF)

>CTAB 1 (= ON)

>CTAB 3 (= INIT)

>CTPS 0 (set correction table position start)

>CTDP 10000 (set correction table distance points)

Setup individual correction table values

>CTPO 20000 (preselect absolute encoder position)

>CTVA 20003 (set correction table value with measured physical absolute position)

Important:

The reference point is also depending on the mechanical precision.

Hence this reference point must be always at the same position

We look for Reference REF 2 times.

Application example for Reference:

>REF Absolute position is calculated anywhere on the linear motor stroke

>G0 Go to absolute position 0

>REF Absolute position is calculated next to the 0 point

This is repeatable at the same position.

>G0 Go to absolute position 0

➔ Now the Linear motor axis is ready

Remark: The position (WebMotion®/ TP „Tell Position“) is the physical absolute position

The POSITION Value is blinking red/white when the correction table is in use.

Influence of Temperature on Measuring System

Besides the position deviation, which can be corrected with the correction table, the temperature influence on the measuring system has to be considered, too.


The deviation due to temperature can't be corrected in the correction table and is about 8.5µm per degree Celsius and meter for the optical measuring system. The optical measuring system

Please refer to data sheet of the according motor.

Examples:

1000mm optical glass scale: per 1° Celsius 8.5µm deviation

230mm optical class scale: Per 1° Celsius 2µm deviation



12.19 Basic Settings

General basic settings

MODE

Choose mode:

Standard	0
Electronic Gear	1
Stepper Control	2
Coded Prog No (standard)	10
Coded Prog No (stepper control)	12

INC PER PULSE


Inc. pro Pulse, MODE 2, Puls/Direction controlling.

SYNC RATIO

Ratio of electronic gear

CARD IDENTIFIER

Master/Slave, CANopen, Powerlink
Read form start-up key (2 x binary coded switch)
or set manual if there is no start-up key.



12.20 Version

Overview of hardware and software versions of
XENAX®, bus module and SMU module.

XENAX®

Overview of firmware, WebMotion® and hardware
version.

BUS-MODULE


Optional bus module with version indication and
protocol type.

Mac-address issue with Profinet / Powerlink and
EtherNet/IP

If the Mac-address is 0, the Card Identifier is missing.
IP address issue with EtherNet/IP

SMU-MODULE

Optional SMU module with version indication.



12.21 Update Firmware / WebMotion®


Loading new version of firmware and new WebMotion® to XENAX® or to bus module or SMU module.

The matching software components and hardware platforms can be found in the release notes.

Firmware

Update of firmware. Select the firmware via Explorer window via mouse click (*.mot).

The download runs automatically and after the installation all functions are available immediately.

**Recommended procedure of firmware download:**

- Save application
- Disconnect PLC-connector and bus module cable if possible.
- We recommend using a point-to-point connection from PC to XENAX®, not via switch.
- After completion of firmware download reset servo controller with command "RES" (reset) in menu *move axis / by command line*
- Reload the application into WebMotion® and download it to servo controller.

WebMotion

The WebMotion® update is done via the [XENAX® Ethernet Installer](#)

Protocol

Update of Busmodul Firmware
(Only available if a bus module is present).

Select and load file (*.flash).

It is recommended to load the corresponding EDS (electronic data sheet) file into the PLC. This is contained in the folder of the firmware.

Safety

Update of SMU Firmware

(Only available if a SMU is present).

Select and download file Safety_Vx.xx.smu

We suggest checking and testing the safety settings after a safety firmware update.

Note:

Alternatively, the [XENAX® Ethernet Installer](#) can be used to update several XENAX® Servocontroller simultaneously.

12.22 Save

Saves applications, which contain all from the client saved parameters, data and programs.

to XENAX


saves applications from WebMotion® to XENAX®.

to file

saves applications from WebMotion® to a file on PC/Laptop (Harddisk, Server).

to start-up key

Saves applications in the start-up key to load faster on other XENAX®.




12.23 Open

Opens applications, which contain all from the client saved parameters, data and programs.

from file

loads an existing application from a file to WebMotion®. Data will be stored into XENAX®.




13 Master / Slave

Please also consult the TUTORIAL video
[JSC Tutorial 5: Programming of a Pick and Place
 System with XENAX Master-Slave](#) on our website.

With the master/slave configuration you can control
 up to 4 axes with one central program.

Typical applications are handlings modules
 (pick&place).

The master controls his slave's autonomously in
 stand-alone operation and can directly be controlled
 by a superior system over simple I/O signals.



13.1 Master/Slave Configuration

Master and slave devices are absolute identical
 standard XENAX® servo controllers.

The I2C bus is interconnected via short standard USB
 patch cables. Both plugs (USB-A) are usable.

No difference between input and output.

The parameter CI (Card Identifier) must be set on the
 involved devices as follows:

Device	CI	Remote ID	
Master	0	LOC (local)	programs
Slave 1	1	REM ID1	-
Slave 2	2	REM ID2	-
Slave 3	3	REM ID3	-

Important:

The program is running on the master servo
 controller.


On the slaves servo controller must be no programs
 loaded.

The start-up key functionality is disabled in
 master/slave configuration and must be
 disconnected.

13.2 Programming example Pick&Place

X-Axis Master (LOC)
Z-Axis Slave (REM ID1)

1	HOME REFERENCE MARK		
2	HOME REFERENCE MARK	REM ID1	
3	EXECUTE INDEX	3	REM ID1
4	EXECUTE INDEX	4	
5	EXECUTE INDEX	1	REM ID1 50%
6	EXECUTE INDEX	2	70%
7	EXECUTE INDEX	3	REM ID1
8	EXECUTE INDEX	1	REM ID1 50%
9	EXECUTE INDEX	4	70%
10	EXECUTE INDEX	3	REM ID1



Please note:

All indices and profiles have to be defined exclusively in the master device. After turning on the devices, indices and profiles will be automatically transferred to the slaves.

13.3 Timing Master / Slave

The program interpreter is triggered in 1ms intervals.
The transmission of a command from the master to the slave takes an additional 0.45ms.


The measurement of time critical sequences is possible with the process timer functionality and the commands: "TIMER_START" und "TIMER_STOP". The process time can be read with the command TPT (Tell Process Timer).

14 Gantry Synchronized Mode

In the gantry mode there are two linear motor axes mounted with the same driving direction. Those two axes have to move synchronously. In this example these are the y-axes marked with the arrows.

When switching on the system, these two Y-axes have to be aligned in order to move without mechanical tension.

The alignment is automatically completed with the function "REFERENCE". For "REFERENCE" function for gantry systems you will need the following information:



The arrangement of the two linear motor axes
Is driving direction from the mechanical absolute zero point the same for both axes or in opposite direction
In which direction should the reference be completed (parameter DRHR)

14.1 Activate Gantry Mode

The axis with which will be communicated by ASCII commands is the master. The slave has to be connected to the master via A-A cable.

The slave has to be assigned a CARD IDENTIFIER between 1 and 3. This can be done by WebMotion® under "setup / basic / CARD IDENTIFIER" or with ASCII command
CI x (where x = 1-3).


The card identifier (CI) can also be assigned with a start-up key and an address from 1 to 3. When turning on the logic supply the next time, this CI number of the start-up key is set.

The master has to be assigned to the number 0 or a different Card identifier (CI) than its slave.

MODE	0-29	0
INC PER PULSE	1-50	0
SYNC RATIO	+/-x:10	0
CARD IDENTIFIER	0-255	1

Corresponds to CI

Master-Slave
USB A-A cable



XENAX®	Parameter	Description
SLAVE	CI	Card Identifier
MASTER	DRHR	Direction of reference drive and arrangement LINAX® / ELAX® linear motor axes.
MASTER	GSID	Gantry Slave ID corresponds to CI Slave

Settings WebMotion®
(settings only necessary on the XENAX® Master)

REFERENCE	<input type="text"/>
DIRECTION	GANTRY <=> POS
SLAVE ID	1

Corresponds to
DRHR

Corresponds to
GSID

The gantry mode is activated with these settings.

14.2 ASCII Commands for Gantry Synchronized Mode

Command	Description
REF	Reference
GP / G	Go Position / Go direct Position
GW	Go Way
IX	Index
PRF	Start profile No. xx
PG	Program
EE*	Emergency Exit
EE1*	Emergency Exit 1
SM	Stop Motion

Can also be triggered as INPUT FUNCTION in the master.

Reference, profile and indices can also be invoked in a program.

Supported by firmware version 3.58 and higher

** EE and EE1 must only be parameterized in a Gantry Master*

15 Force Process Forceteq®

15.1 Overview Forceteq® Functions

The force processes of the XENAX® servo controller cover four FORCE functions:

- **FORCE CALIBRATION:** Calibration of the motor through detection of all idle running forces including the payload of the client specific installation on the slide. This creates the basis to precisely determine the external application forces.

- **FORCE LIMITATION:** Driving with limited force to an object or an end position if there are no objects (e.g. inserting parts). Or driving with very little force in order to detect an “object’s touching position”.

- **FORCE MONITORING:** Monitoring the force progression by defining sectors in a force/ way diagram (e.g. inspecting switches). These sectors can automatically be adjusted towards the “object’s touching position”.

- **FORCE CONTROL:** Integration of different FORCE functions into a program. This is how it becomes possible to use the force processes decentrally in the standalone operation mode. Of course these FORCE functions can also be invoked by a superior PLC through Ethernet fieldbus.




15.1.1 Force Calibration

With the patented function „force calibration“ of the XENAX® servo controller, the cogging-, load- and friction forces of the iron core LINAX® and ELAX® linear motor axes and the ROTAX® rotary axes from Jenny Science can be detected.

This is how it becomes possible to limit, monitor and control forces in processes.

START: Determining the beginning position of calibration process in increments.

END: Determining the ending position of calibration process in increments.



← Normal operation, calibration active
← Test calibration active
← Test without calibration

In order to increase the accuracy of the detected forces at temperature variations, the temperature drift of the detection is continuously compensated at disabled power stage. The compensation also takes place before each start of a „force calibration“.


15.1.2 Force Limitation

The current value „I_Force“ is proportional to the force. Following graph shows corresponding relations for the different linear motor types.

LINAX® Linear Motor Axis	Force Constant	Minimal detectable force	Resolution
Lxc F04	50 * 10mA ~ 1N	0.5N	0.25N
Lxc F08	32 * 10mA ~ 1N	0.5N	0.25N
Lxc F10	28 * 10mA ~ 1N	0.5N	0.25N
Lxc F40	11 * 10mA ~ 1N	1N	0.5N
Lxe F40	11 * 10mA ~ 1N	10N	5N
Lxu/Lxs F60	10 * 10mA ~ 1N	10N	5N

ELAX® Linear Motor Slide	Force Constant	Minimal detectable force	Resolution
Ex F20	12 * 10mA ~ 1N	0.5N	0.25N

ROTAX® Rotary Motor Axis	Torque Constant	Minimal detectable torque	Resolution
Rxhq T0.3	7 * 10mA ~ 0.01Nm	0.02Nm	0.01Nm
Rxvp T0.04	23 * 10mA ~ 0.01Nm	0.006Nm	0.003Nm



Example:


A compression die should apply no more than 4N force on an object.

Force Limitation with „LIMIT I-FORCE“
e.g.. ELAX® force constant: 12 x 10mA ~ 1 N
48 x 10mA ~ 4 N

15.1.3 Force Monitoring

15.1.3.1 Diagram I_Force

In the menu „Diag I_Force“ the way/force diagram can be recorded by which the force progression through the sectors can be verified.




15.1.3.2 Sector I_Force

In the WebMotion® program menu „sector i-force“ up to 10 different force sectors can be defined.


Example:

Once an object is touched the force progression shall be examined in a sector of 150 to 170 Increments. When entering the force sector (“ENTRY”) the force should be between 3 and 4N. When exiting the sector (“EXIT”), the force should have reached 4N. These force specifications are defined with the in the force sector incoming and exiting sector boundaries.



Force Specification Examples:

- 1) Force curve has to pass through sector from the left/bottom side to right/top side.
- 2) Force curve has to pass through sector from the bottom to the top side.
- 3) Force curve has to reach the sector and can pass through incoming and exiting force boundaries multiple times.



Note:

If there are defined incoming and exiting force boundaries, it is absolutely necessary that the force curve passes through them. If there are no incoming force boundaries defined, the force curve has to begin somewhere within the force sector. If there are no exiting force boundaries defined, the force curve has to end within the force sector.

15.1.4 Force Control

15.1.4.1 Program with Force Control Commands

In the WebMotion® menu „program“ the different force functions of FORCE CALIBRATION, FORCE LIMITATION and FORCE CONTROL can be combined and defined with the use of the according commands.

The screenshot shows the 'PROGRAM' menu in WebMotion. At the top, there are controls for 'NEW', 'NUMBER' (set to 3), 'COPY TO', and 'CLEAR'. Below this is a list of 'LINES' with the following commands and values:

Line	Command	Value	Reference
8	DRIVE I_FORCE	1	
9	WAIT TIME	50 ms	
10	WAIT LIMIT I_FORCE	2000 ms	Line 22
11	TAKE POS AS SECTOR OFFSET		
12	SELECT SECTORS	11111	
13	CHANGE LIMIT I_FORCE	150	
14	WAIT LIMIT I_FORCE	2000 ms	Line 25
15	WAIT TIME	50 ms	
16	DRIVE I_FORCE END		
17	JUMP IF I_FORCE SECT FAULT		Line 24

At the bottom, there is an 'EDIT LINE' section with a dropdown menu showing '27' and buttons for 'CLEAR', 'SET', and 'INSERT'.

15.1.4.1 Drive I_Force

DRIVE I_FORCE is driving with force consisting of acceleration (ACCEL), speed (SPEED), current (I_FORCE) and driving direction (DIRECTION).

After defining and saving the above mentioned parameters, DRIVE I_FORCE can be included in a program.

Up to 10 DRIVE I_FORCE can be defined.

The screenshot shows the 'EDIT' menu for 'Drive I_Force'. It contains the following sections:

- EDIT**: 'NEW DIF' and 'CLEAR DIF' dropdown menus.
- CURRENT DIF**: 'NR' dropdown menu and 'COPY TO' dropdown menu.
- PARAMETERS**:
 - 'ACC x1000': input field with value 0.
 - 'SPEED': input field with value 0.
 - 'DR_I_FORCE': input field with value 0, followed by 'x10mA'.
 - 'DIRECTION': dropdown menu with 'POS' selected.
 - 'FORCE CONSTANT': '1N ~ 28 x 10mA'.

15.2 Integration of Force Processes

15.2.1 XENAX® in Program

15.2.1.1 Programming Commands

Description	Command	Parameter	Master /Slave
Executing Force Calibration, Start Pos xx, End Pos yy	FORCE CALIBRATION	xx, yy	
Automatic I_Force Drift Compensation drive xx = POS => drive in positive direction xx = NEG => drive in negative direction	I_FORCE DRIFT COMPENSATION	xx, yy	
Execute DRIVE I_FORCE No. xx	DRIVE I_FORCE	xx	
Selection of active sectors with Bit mask. E.g. xx = 1010 → sectors 2 and 4 are active. LSB is on right.	SELECT SECTORS	xx	
Jump to line xx "error handling" if one or more sectors are not passed correctly. Only active sectors are being tested. Caution: Before this analysis can be done, "DRIVE I_FORCE END" has to be completed.	JUMP IF I_FORCE SECTORS FAULT	xx	
Wait until Limit I_FORCE is reached according parameter DRIVE I_FORCE within timeout xx, otherwise jump to line yy „error handling“	WAIT LIMIT I_FORCE	xx, yy	
Changing Limit DR_I_FORCE to xx x 10mA Value of I_FORCE will overwrite the current parameter I_Force in DRIVE I_FORCE until DRIVE I_FORCE END	CHANGE LIMIT I_FORCE	xx	
Is taking the actual position as offset value for all sectors followed by the restart of monitoring. Furthermore the positions "Wait for distance greater/less" and "Jump if distance greater/less" are being adjusted by the offset as well.	TAKE POS AS SECTOR OFFSET (typically touching position , also refer to chapter 15.2.3 Sector Offset for Touching Position)		
Setting offsets for all sectors followed by the restart of monitoring. xx = [Inc] Offset Furthermore the positions "Wait for distance greater/less" and "Jump if distance greater/less" are being adjusted by the offset xx as well. e.g. xx = 0, sets offset incl. TAKE POS AS SECTOR OFFSET to 0	SET SECTOR OFFSET	xx	
Wait for distance (absolute position – Sector Offset) to be greater than xx within timeout frame yy, otherwise jump to line zz „error handling“	WAIT FOR DISTANCE GREATER	xx, yy, zz	
Wait for distance (absolute position – Sector Offset) to be smaller than xx within timeout frame yy, otherwise jump to line zz „error handling“	WAIT FOR DISTANCE LESS	xx, yy, zz	

Description	Command	Parameter	Master /Slave
Jump to line zz if distance xx (absolute position – sector offset) greater than xx e.g driving distance was too big after force was reached	JUMP IF DISTANCE GREATER	xx, zz	
Jump to line zz if distance (absolute position – sector offset) smaller than xx e.g. driving distance was too small after force was reached	JUMP IF DISTANCE LESS	xx, zz	
Wait for input No. xx to be High within timeout frame yy, otherwise jump to line zz „error handling“	WAIT INPUT Nr. HIGH	xx, yy, zz	MS
Wait for input No. xx to be Low within timeout frame yy, otherwise jump to line zz „error handling“	WAIT INPUT Nr. LOW	xx, yy, zz	MS
Wait for process status register Bit xx High within timeout frame yy, otherwise jump to line zz „error handling“	WAIT PROCESS STATUS BIT HIGH	xx, yy, zz	
Wait for process status register Bit xx Low within timeout frame yy, otherwise jump to line zz „error handling“	WAIT PROCESS STATUS BIT LOW	xx, yy, zz	
Stop Drive I_Force, current position = setpoint position, parameter LIMIT DR_I_FORCE inactive	DRIVE I_FORCE END	xx	
Program is being ended and does not proceed to last line. Beneficiary for „error handling“	PROGRAM END		

15.2.1.2 Input Functions Commands

Selection Input Functions

Program exit Stop Motion (if driving) and then exiting the current program	PGEX	
Driving with I_Force No xx [1-10] (pre-programmed)	DIF	xx

15.2.2 Over Command Set

15.2.2.1 ASCII Commands

Description	Commands	Parameter	MS
Force Calibration xx=0 -> Reset, deleting all calibration values xx= [Inc] -> calibration distance from current position	FC	xx / ?	
(Force Calibration Test) testing force calibration xx=0 -> Servo on, in position control xx =1-> test floating slide in balance with calibration function xx=2-> test slide without calibration function	FCT	xx	
Automatic I_Force Drift Compensation Drive in positive direction	IFDCP		
Automatic I_Force Drift Compensation Drive in negative direction	IFDCN		
I_Force Drift Compensation Settings, bitwise coded: Bit0: Continuous compensation at power stage disable Bit1: Automatic compensation before force calibration Bit2: Continuous compensation at enabled power stage at applicable position (see command PIFDC)	IFDCS	0-7 / ?	
Position for I_Force Drift Compensation at enabled power stage, depending on the motor type	PIFDC	?	
(Drive I_Force) Driving with limited force until reaching an object or the end position if there is no object. xx= [1-10] No. of the selected Drive I_Force parameter set	DIF	xx	
Change Limit DR_I_FORCE to xx x 10mA value xx will overwrite the current parameter DR_I_Force, until DRIVE I_FORCE END	CLIF	xx	
Select sectors which should be active. E.g. xx = 100110-> active are the sectors 2,3,6 Binary from right side LSB	SSEC	xx / ?	
(I_Force Peak) Reads I_FORCE peak value [x1mA] xx=not defined-> Max peak value over all sectors xx=n-> peak value of sector n	IFPK	xx	
(Sectors I_Force curve failed) shows the active sectors which force curve did not correctly pass through E.g. xx = 1001->Error in sector 1 and 4.	SIFF	xx / ?	

<p>(Take Position as Sector Offset)</p> <p>Is taking current actual position as an offset for all sectors with restart of monitoring.</p> <p>Furthermore the positions „Wait for distance greater/less“ and „Jump if distance greater/less“ are adjusted by this offset.</p>	<p>TPSO</p> <p>(typically touching position , also refer to chapter 15.2.3 Sector Offset for Touching Position)</p>	
<p>Provide offset for all sectors with restart of monitoring.</p> <p>xx = [Inc] offset</p> <p>Furthermore the positions „Wait for distance greater/less“ and „Jump if distance greater/less“ are adjusted by this offset xx.</p> <p>E.g. xx = 0, sets offset to 0</p>	<p>SSO</p>	<p>xx / ?</p>

Changing Parameters over ASCII Commands

(Number of Sector for change parameter)
Selecting sector number for which parameters shall be changed. xx = [1-10] Sector number, NSEC? = Retrieving the selected sector number.

NSEC

xx / ?

Deriving commands:
SIFS, SIFE, IFH, IFL,
STC, STCX

(Sector I_Force Start) start distance of sector
xx = [Inc] start distance (absolute position
– sector offset)

SIFS

xx / ?

(Sector I_Force End) End distance of sector
xx = [Inc] ending distance (absolute position
– sector offset)

SIFE

xx / ?

(I_Force Low) lowest value I_Force in pre-selected
sector. xx [x10mA]

IFL

xx / ?

(I_Force High) peak value I_Force in preselected
sector. xx [x10mA]

IFH


xx / ?

(Sector transition configuration hexadecimal/decimal)
Definition of transitions **Entry** and **Exit** in sector
xx = activated transition 1,2,3,4 Entry/Exit

STCX (hex)
STC (dec)

xx / ?

Bit 15..12	11..8	7..4	3..0	xx
Entry	not used	Exit	not used	
4 3 2 1	0	4 3 2 1	0	Transition
0 0 0 1	0 0 0 0	0 0 1 0	0 0 0 0	bin
1	0	2	0	hex
			4128	dec



(Number of Drive I_Force to change parameter)
Selecting Drive I_Force number in which parameters
shall be changed.
xx= Drive I_Force number 1-10. NDIF? =
Retrieving selected sector number

NDIF

xx / ?

Deriving commands:
IDIF, DDIF, SDIF, ADIF

(Acceleration for Drive I_Force)
xx [x1'000 inc/s²]

ADIF

xx / ?

(Speed for Drive I_Force)
xx [inc/s]

SDIF

xx / ?

(I_Force Limit while Drive I_Force)
Limitation of I-Force current while Drive I_Force
xx [x10mA]

IDIF

xx / ?

(Direction Drive I_Force)
xx = 0 -> positive, xx = 1 -> negative

DDIF

xx / ?

(?) = Retrieving possibility of parameter value by adding
a question mark to the command. E.g >NDIF? -> 2

15.2.3 Sector Offset for Touching Position


Typically an object is first touched. All following functions then relate to this touching position. Depending on the size tolerance of the objects, this touching position differs from object to object.

The touching position can very simply be detected with „Drive I_Force“ (by using little force). The command „TPSO“ (Take IST-Position as Sector Offset) will take this touching position as sector offset for all functions that follow.

In order to determine the value „Sector I_Force Start“ and „Sector I_Force End“ it is simplest to record the force curve and to calculate the distance to touching position (absolute position – Sector Offset).

„Sector I_Force Start“, „Sector I_Force End“, „Wait for Distance greater/less“ and „Jump if Distance greater/less“ are distances relative to the touching position (sector offset).


With „SSO“ Set Sector Offset = 0 the distances correspond to the absolute positions.




15.3 Application Example

A force sensor consisting of a little mounting plate, ceramic and strain gauge elements glued on the top shall be tested upon its functionality.


The force sensor measures the external force applied to the small ball (upper left corner in picture).



With the ELAX® linear motor slide and the XENAX® servo controller the ball shall be touched and the touching position detected. The touching position is the offset of the actual force curve measurement. This offset compensates the height tolerances of the different measuring objects.



After touching position, the force curve of the ceramic plate shall be recorded. After an air gap of only 200 µm, the ceramic plate hits the rubber buffer. At this position the force increases steeper as the rubber buffer acts against the ceramic plate. The maximal force is limited to approximately 12N ~150 x 10mA. Of interest is the increase in force while the plate is bending and the position where the force curve is making a kink upwards when hitting the rubber buffer. For this example, five different sectors are defined on the force-/way curve, which have to be passed correctly.



Hereinafter you can find the according program example 1) as stand-alone version programmed and stored in the XENAX® servo controller 2) as Ascii command set controlled via a superior controller.

15.3.1 Programming Force Process in XENAX®

Input / Output Interface Definition

INPUT FUNCTIONS:

Input 1 = Program 1, Referencing and drive to position 0
 Input 2 = Program 2, Force Calibration of ELAX® linear motor slide
 Input 3 = Program 3, Entire test process including analysis

OUTPUT „STATUS“:

Output 1 = No touching position found → No test object available
 Output 2 = Error of test object
 Output 5 = Test object OK

INDEX, DRIVE I_FORCE und SECTORS

Drive INDEX 1 to 0Inc. absolute
 (1Inc = 1µm)

***** Index 1*****

Acc x1000 = 1000
 Speed = 100000
 Dist = 0
 AbsRel = 1

Drive INDEX 2 to 30'000Inc. absolut

***** Index 2*****

Acc x1000 = 1000
 Speed = 100000
 Dist = 30000
 AbsRel = 1




Drive with Force, Force on 0.5N in order to recognize touching position.
 (1N = 12 x 10mA)

***** Drive I_Force 1 *****

Acc x1000 = 100
 Speed = 5000
 IForce x10mA = 6
 Direction = 0

In order to determine the following sector parameters, we recommend the following approach:

1. Drive towards test object (Drive I_Force) with little force (e.g. 0.5-1.0N) and remember the touching position (offset corresponds to the position at arrowhead)
2. Record Force/Way diagram of a correct test object. Then place the testing sectors according to the force curve and retrieve parameters. For Sector I_Force Start/End the offset has to be subtracted of the touching position.




***** Sector I_Force 1 *****

Sector IForce Start = 31
 Sector IForce End = 58
 IForce Low x10mA = 25
 IForce High x10mA = 35
 Sector Transit Config = 12480


***** Sector I_Force 2 *****

Sector IForce Start = 100
 Sector IForce End = 130
 IForce Low x10mA = 65
 IForce High x10mA = 75
 Sector Transit Config = 12480




***** Sector I_Force 3 *****

Sector IForce Start = 158
Sector IForce End = 178
IForce Low x10mA = 119
IForce High x10mA = 121
Sector Transit Config = 8320



***** Sector I_Force 4 *****

Sector IForce Start = 162
Sector IForce End = 182
IForce Low x10mA = 139
IForce High x10mA = 141
Sector Transit Config = 8320



***** Sector I_Force 5 *****

Sector IForce Start = 170
Sector IForce End = 185
IForce Low x10mA = 148
IForce High x10mA = 152
Sector Transit Config = 12288

No „EXIT“
Ending position has to be in sector.

Referencing and driving to position 0, INDEX 1

***** Program 1 *****

Line 1 REFERENCE
Line 2 INDEX 1, DEVICE = LOCAL COMPLETION = 100%

Calibration of linear motor slide by recording all forces
(cogging, friction, weight etc.)

***** Program 2 *****

Line 1 FORCE CALIBRATION POSITION START = 0 POSITION END = 50000

Entire testing process with analysis of result

***** Program 3 *****

Reset output status display

Line 1 CLEAR OUTPUT 1 M/SLAVE DEVICE = LOCAL
Line 2 CLEAR OUTPUT 2 M/SLAVE DEVICE = LOCAL
Line 3 CLEAR OUTPUT 5 M/SLAVE DEVICE = LOCAL
Line 4 SET SECTOR OFFSET POSITION = 0
Line 5 SELECT SECTORS 0

Initializing sector offset to 0 (not mandatory)
Selected sectors 0 (not mandatory)

Line 6 INDEX 1 LOCAL COMPLETION = 100%
Line 7 INDEX 2 LOCAL COMPLETION = 100%
Line 8 DRIVE I_FORCE 1
Line 9 WAIT TIME TIME [ms] = 50
Line 10 WAIT LIMIT I_FORCE TIMEOUT = 2000ms LINE = 23
Line 11 WAIT TIME TIME [ms] = 20
Line 12 TAKE POS AS SECTOR OFFSET
Line 13 SELECT SECTORS 11111

Drive to position 0, all the way to the top
Drive to position 30000, fast driving to pre-position
Drive to touching position with little force (0.5N)
Short wait time, in case the force has been exceeded while
accelerating (when using little forces).
Wait until LIMIT I_FORCE is reached. If there is no touching
position during timeout frame, jump to error
“no object in place”, output 1 ON
Short wait time in order to stabilize touching position
Takes touching position as offset for the following tests
Selecting sectors 1-5

Change I_FORCE for current Drive I_Force from, 6 to 150 = 12.5N
Timeout in case that force is not reached, then no output no 5.
Short wait time after force reaches limit to “stabilize”.

Line 14 CHANGE LIMIT I_FORCE I_FORCE = 150
Line 15 WAIT LIMIT I_FORCE TIMEOUT = 2000ms LINE = 26
Line 16 WAIT TIME TIME [ms] = 20

Drive I_Force ends
Testing the selected sectors, in case of an error, jump to error
output 5 ON, meaning testing object OK

Line 17 DRIVE I_FORCE END
Line 18 JUMP IF I_FORCE SECT FAULT LINE = 25
Line 19 SET OUTPUT 5 M/SLAVE DEVICE = LOCAL
Line 20 SELECT SECTORS 0
Line 21 INDEX 1 LOCAL COMPLETION = 100%
Line 22 PROGRAM END

Line 23 SET OUTPUT 1 M/SLAVE DEVICE = LOCAL
Line 24 GOTO LINE 26


Line 25 SET OUTPUT 2 M/SLAVE DEVICE = LOCAL
Line 26 DRIVE I_FORCE END
Line 27 INDEX 1 = LOCAL COMPLETION = 100%

15.3.2 Force Process with ASCII Commands

Download the determined sector parameters into
XENAX® servo controller.

There are 5 sectors all in all.

Below you find the description for sector 1. Sectors 2-5 are structured in the same way.



Pre-selection of sector number
Sector I_Force Start [Inc]
Sector I_Force End [Inc]
IFL I_Force Low [x10mA]
IFL I_Force High [x10mA]
Sector Transition Configuration

Parameter Sector 1 laden


```
>NSEC 1
>SIFS 31
>SIFE 58
>IFL 25
>IFH 35
>STC 12480
```

In order to be able to see those parameters in the webbrowser under
"sector i_force", the site has to be re-loaded. This is how the values
are transferred from the XENAX® to the Webbrowser.

Calculate STC parameter with Win Calc (view of
programmer)

Decimal value can be negative if highest Bit, Entry 4 is
set.

Bit 15..12	11..8	7..4	3..0
Entry	not used	Exit	not used
4 3 2 1	0	4 3 2 1	0
0 0 1 1	0 0 0 0	1 1 0 0	0 0 0 0



Program

Referencing Axis
Drive to position 0

```
>REF
>G 0
```

Remove test objects, axis has to drive without obstacles.
Execute Force Calibration from 0 until 50000 Inc (one-time)

Old calibration values are deleted beforehand.

Force Calibration test, if slider is floating / in balance (optional)

Back to position control (optional)

```
>FC 50000
```

```
>FCT1
>FCT0
```

Sector Offset is set to 0 (optional)

Selection of active sectors of 0. Only to be activated before test drive,
so the analysis SIFF is correct.

Drive to position 30'000 Inc

```
>SSO 0
```

```
>SSEC 0
>G 30000
```

Reduce Deviation Position, so the internal calculated desired position
does not deviate too much from the actual position of Drive I_Force.

Otherwise the slide would jump in position when

I_Force is increased. Only needed when there are long timeouts after

Drive I_Force is reached.

```
>DP100
```

Drive I_Force 1 moves to touching position

Take Position as Sector Offset (touching position)

Activate sectors 1-5

Change Limit I_FORCE to 150 x 10mA

Verify tell process status registry, Bit 5 „IN FORCE“

```
>DIF 1
>TPSO
>SSEC11111
>CLIF 150
>TPSR
```

Stop Drive I_Force with Stop Motion

Shows faulting sectors. Response should be 0

Reset Deviation Position to old value

Drive to position 0

```
>SM
>SIFF?
>DP1000
>G 0
```

15.3.2.1 PSR Prozess Status Register

Bit coded process status, return string displays three bytes in HEX format.

ERROR = BIT 0

REF = BIT 1

IN_MOTION = BIT 2

IN_POSITION = BIT 3

END_OF_PROGRAM = BIT 4

IN_FORCE = BIT 5

IN_SECTOR = BIT 6

FORCE_IN_SECTOR = BIT 7

INVERTER_VOLTAGE = BIT 8

END_OF_GANTRY_INIT = BIT 9

NEGATIVE_LIMIT_SWITCH = BIT 10

POSITIVE_LIMIT_SWITCH = BIT 11

EMERGENCY_EXIT_1, REMAIN POWER ON = BIT 12

(Function can only be used **without** bus module. If used **with** bus module apply "EMERGENCY_EXIT").

EMERGENCY_EXIT, POWER OFF = BIT 13

FORCE_CALIBRATION_ACTIVE = BIT 14

I_FORCE_LIMIT_REACHED = BIT 15

STO PRIMED/HIT = BIT 16

SS1 PRIMED/HIT = BIT 17

SS2 PRIMED = BIT 18

SS2 HIT = BIT 19

SLS PRIMED = BIT 20

SLS SPEED HIT = BIT 21

SLS POSITION HIT = BIT 22

WARNING = BIT 23

DISPLAY INFO ONLY = BIT 24

PHASING DONE = BIT 25

I_FORCE_DRIFT_COMPENSATION_DRIVE_ACTIVE = BIT 26

Tell Process Status Register **TPSR**

16 Operating Status on 7-Segment Display

Description	Display
No firmware, operating system is active	F
Firmware active, servo controller OFF	0
Servo On, control loop closed	1
Error (refer to chapter 17 Error Handling)	xx flashing
No power supply logic or voltage on power supply logic >27VDC (all XENAX models have over voltage protection except XENAX Xvi75V8 HW < 3.00).	none



17 Error Handling

Errors are displayed on the XENAX® servo controller's 7-segment display by flashing a two digit number. With the command „>TE“ (Tell Error) they can be retrieved.

There are 3 different categories to differentiate:

Information	No 0-39	They do not change state of the servo controller. These are simple status indicators.
Warnings	No 40-49	They can trigger a stop of an active drive (e.g. driving in soft limit). However, the drive can then be continued without the need to switch off the output stage.
Errors	No 50-99	Always cause the output stage to switch off. The drive can only be continued after troubleshooting.

The first information/warning/error is always displayed first. A possible follow-up error won't be displayed. Each warning can overwrite information and each error can overwrite a warning or information. The error history can be retrieved with AXII command TEB.

17.1 Error Codes

F-Number	Description	Note
Information		
01 to 12	Waiting for input xx (Low od. High)	Keeps driving, if status has been reached or restart with HO, REF, SM, or PQ, PWC.
20	Command not allowed	Command is not allowed, if an external PLC is controlling the axis. The command priority of the overriding PLC can be deactivated if the user set the CANopen Mode of operation to 0 (CANopen Object 0x6060)
21	Force license missing	Calibration value are existing in motor, but there is no force license active
22	Program start interrupted	Program start is interrupted through input function "IP"
23	Starting position of motion profile is not valid	Motion profile (ASCII command "PRF") can only be started if linear motor slide is positioned at or behind the starting position of the motion profile.
24	Index Paramater not valid	One or more parameters of the most previous selected index are not valid. Please check Acceleration (ASCII-command „AIX“), Speed (ASCII-command „SIX“) and type (ASCII-command „TYIX“) of index.
25	Bus module supervision disabled	Bus module is only intended for development purposes. Change bus module by Jenny Science.
26	Third party motor not configurated or DIP-switch setting wrong	For Jenny Science Motors (LINAX/ELAX/ROTAX): For all Jenny Science motors the DIP-switch has to be set on „LINAX/ELAX/ROTAX“ (pls refer to chapter 7, Configuration Motor Type Jenny Science / Motor customer specific). For third party motors: Please make correct setting for the motor in WebMotion® under setup → motor.
27	Swing Out Reduction Parameter inconsistency	A new calculation of the target trajectory for swing out reduction feature can only be initialized after a motor standstill -> Motor has to be at standstill for at least 1000ms so that a new set of parameters can be used.

30	Limit I Force reached	Force proportional motor current reached "Limit I_Force Value" (LIF). Motor current is limited to "Limit I_Force Value". A possible detected error 50 (position deviation to large) is suppressed.
31	I_Force Drift Compensation failed	Automatic I_Force Drift Compensation drive was blocked or the compensation position could not be held steady for 150ms (e.g., due to vibration)
Warnings		
40	Driveway limitation due to soft limit values	Soft limits can be adjusted in WebMotion® in menu „move axis / by click“.
41	HW-Limit switch positive/negative active	HW-Limit switches are defined as input function LS+/LS-
42	Remote Controller Command rejected	One of the slave axes has an error or command for the slave could not be executed
43	Remote Controller not recognized	Master Slave configuration: Not all remote controllers defined in the master were recognized. The programs in the master have to be checked and the invalid remote controllers (Rem ID) have to be deleted.
44	Remote controller communication error	Check Master/Slave cable
45	AD Offset Error	The AD-Offset for measuring the current could not be retrieved correctly during the first drive. The linear motor has to be turned off while the output stage is turned on for at least 0.5s, so the AD-Offset can be retrieved correctly.
46	Cyclic data are not valid	Cyclic data specified via the bus modules are not valid. Check the Data S-Curve, Deviation position, Deviation Target position, I Force Max, Speed and Acceleration. Or PDO cycle time it not correct (only a multiple of 100us is valid).
47	Drive interrupted through SMU	The current drive was interrupted through the functional safety SS2 or SLS.
Errors		
50	Position deviation is too large.	The difference between the internal calculated position and the present motor position (encoder) is larger than the value defined as DP (deviation position) in Closed Loop setup. Refer to chapter 17.2 Notes for Error 50
54	Excessive rise of temperature or weak signal of LINAX® read head	Temperature rise too high/fast or the signal in the detector head of the measuring system is too weak. Check our drive profile or clean glass scale on LINAX® linear motor.
55	Excessive rise of temperature	Temperature rise too high/fast. Check our drive profile.
59	JSC Motor does not fit application data	Connected JSC motor does not fit to the motor stored in application data (e.g. if a new JSC motor type is connected to the servo controller). Motor type reset (RESM) is required.
60	Over-temperature power stage	Above 85° detected by separate temperature sensor on power stage. Power stage will be switched off.
61	Overvoltage of power supply	Power supply voltage or retarding energy from motor too high. Error occurs only if power stage is turned off. If power stage is turned on, please refer to error code 62.
62	Ballast circuit too long active	The ballast circuit is still more than 5 sec continuously active: Retarding energy too high or the power supply voltage is too high, the power stage will be switched off.
63	Over-temperature LINAX®/ELAX®/ROTAX®	Coil temperature above 80° in LINAX® / ELAX® linear motor or ROTAX® rotative axis. Power stage will be switched off.
64	Under voltage of power supply	Motor power supply voltage is too low. The power supply probably is not able to temporary deliver the demanded current.
65	Field adjustment on the magnet poles	The adjustment on the magnet pole was not successful, travel-plate of LINAX® / ELAX® or rotor of the third party motor is blocked or encoder / motor cable is broken. If at multi-axis applications, all servo controllers show error 65, then the D-sub encoder connector is unplugged at one axis. Check the value payload (ML).

66	REF error	Push the travel-plate by hand to a "free range" and try "REF" again. Check the values I stop (IS) and I run (IR), maybe you have to increase these values.
67	Z-Mark distance failure	The measured distance of coded reference marks is not plausible. Check the value payload (ML). Execute "REF" again.
68	Velocity too high during REF	Execute REF again. Could be consecutive fault of vector field adjustment on the magnet pole. Check the values I stop (IS) and I run (IR), maybe you have to increase these values.
69	Error HALL signal	Error in the consecutive order of HALL-signals, check Encoder cable.
70	Over-current power stage	Potential short circuit or accidental ground in motor cable / coils.
71	Power stage disabled	Release signal via PLC I/O Pin 9 not present (if activated) or power stage is disabled by Safe Motion Unit (SMU)
72	Speed is too high	Maximal speed. For 100nm measuring option $= 9'000'000 \text{ inc/s} = 0.9\text{m/s}$
73	Over-temperature (I2T)	I2T calculation has detected over-temperature in the coil.
74	Electrical Angle Failure	The calculated electrical angle differs more than 50° from the estimated angle. Interrupt power and execute REF again. Cleaning the measuring scale might also be necessary. Check the values I stop (IS) and I run (IR), maybe you have to increase these values.
75	Reference pending	REF has to be executed before motor can move
76	Gantry Master Slave Offset	Difference between automatically measured Gantry Master Slave Offset and pre-set value through PGMSO great than 0.5mm
77	communication error bus module/serial port	Depending on the operation mode, please check communication between servo controller and bus module or communication over serial interface (RS232/Ethernet). For communication over serial interface adjust Watchdog time if necessary (command „WD“)
78	MAC-address not valid	The XENAX® Xvi48V8 MAC-address is not valid, please contact the Jenny Science AG company
79	Wrong checksum of calibration data	Force calibration or position of mechanical limit wrong. Restart "Force calibration" (ASCII: fcxx) or "mechanical limit calibration" (ASCII: mlc).
80	Over-current PLC Output	One or more outputs of the PLC interface are overloaded In source configuration is $I_{\text{max,out}}=100\text{mA}$ per channel, in sink Configuration is $I_{\text{max,out}}=400\text{mA}$ per channel. Error can potentially occur due to inductive load without free-wheeling diode. In this case please either insert free-wheeling diode or select Sink/Source configuration with $I_{\text{max,out}}=100\text{mA}$ per channel.
82	Communication error I2C bus to the motor	Check encoder and extension cables. Connect cable shields on servo controller and motor with GND. Check Master / Slave cables
83	Internal FRAM error	Permanent data storage not possible ¹ . Possible source of error like in error display "L".
84	Start-up key error	Test with other key. Functionality in master-slave mode not supported.
85	I2C switch error	Test without master-slave cables.
86	wrong checksum of application data	This error can appear after firmware download. Execute reset (RES)
87	Remote controller missing	Master Slave configuration: One or more remote controllers defined in master are missing. Check master programs for non-existent controllers (RemID) and delete them out of programs.
88	General I2C error	Check the cable to the motor or the master-slave cable
89	SMU error	Critical error of the safety motion unit. Details to the cause and possible fix are given by WebMotion® as soon as error occurs. Please refer to chapter 17.3 Notes for Error 89
90	Functional Safety active	If safety function was active, the observation was triggered and the SMU (Safety Motion Unit) module has turned off the power stage. For SS2 or SLS, the ED (Emergency Deceleration) potentially was too small for Stop Timeout.
91	SMU Error	Error of Safety Motion Unit or motion blocked by unconfigured SMU. Details to the cause and possible fix are given by WebMotion® as soon as error occurs. Please refer to chapter Kapitel 17.4 Notes for Error 91.

92	3-Phase Output frequency > 599Hz	The output frequency of the 3-phase motor is over 599Hz. There are only movements allowed, which do not lead to an output frequency of >599Hz.
93	Encoder plausibility	The encoder signals are not plausible. Possible causes: interruption of strands in the encoder cable, or encoder signals are led asymmetrically only. When encoder signals are led asymmetrically by intention for rotary motors, the encoder plausibility check can be turned off (refer to command ENCPD).
94 („EE“)	Restart caused by exception	XENAX® restarted due to software exception. Contact Jenny Science for details.
95	License missing	License error, a programmed function could not be started while the necessary license is missing.
96	Firmware Checksum Failure	Please try to reload the XENAX® firmware again. If the error persists, please contact Jenny Science.
97	Interlaced warnings	A new warning occurred before the state which led to the previous warning was cleared. Please make sure process is setup in a way where warnings cannot interlace (e.g. drive in soft limit and then drive in limit switch, before soft limit was left).
98	AD Interrupt Nesting	Fatal Error – Please restart the XENAX® servo controller.
99	Encoder cable unplugged/disconnected	Motor encoder cable was disconnected. Please connect encoder cable again and restart XENAX®.
„L“	Level I2C Bus	The Level of the I2C bus is not ok. Bus is blocked. Rotary motor connected to a XENAX® controller with linear axis setup (DIP Switch)? Or servo controller encoder connector defect. Test encoder: disconnect encoder; if XENAX® starts normally, connector is defect. If still not working, please contact Jenny Science for support.
„n“	Level I2C Bus	I2C bus response is „nak“ (not acknowledged) No communication on I2C bus, XENAX® internal or LINAX®/ELAX®/ROTAX®, temperature check is not possible.

¹⁾ Internal hardware failure of the device, please contact Jenny Science

17.2 Notes for Error 50

Error 50 means that deviation from position target value to actual position value is higher than „DEVIATION POS“ (→ *WebMotion®*, *setup*, *state controller*).


There are different possible causes which lead to this error. Please check the following:



Test POSITION Encoder counter

Status Display XENAX® WebMotion®

When the carriage slider of a linear motor axis or the rotary linear motor is being moved by hand, the position encoder counter has to adjust accordingly. If not check cable, signal encoder (check A/A* and B/B*).



If a shaft of a rotary motor is being turned clockwise (when looking at front shaft), the POSITION encoder counter has to count positive. When turned counter clockwise, the POSITION encoder counter has to count negative. Compare to chapter 6.2.5 Definition of Rotating Direction for Servo Motors.

Check parameters in setup

I STOP	sufficient?
I RUN	sufficient?
DEVIATION POS	2000 (Default)
DEVIATION TARGET POS	50 (Default)

Check power supply unit

Is there enough voltage and enough power supply?

For LINAX® rotating field adjustment

Lxc F04 at least 5,2A

Lxc F08 at least 6,1A

Lx F10 at least 5,5A

Lx F40 at least 6.0A

Lx F60 at least. 8.0A

For ELAX® rotating field adjustment

Ex F20 at least 5,5A

When using LINAX® linear motor axes and ELAX® electric slides, we suggest executing the Quick Start function with automatic system-check.

Test of brushless servo motors for hall signals encoder A/B and motor phase (wiring and colors).

There is no common standardization for servo motor connectors. Jenny Science is happy to support you during the setup process.

Test if motor is running at low velocity

With WebMotion®

Menu Motion:
S-CURVE 20%
AC (x1'000) 100
SPEED 10'000
Power
Rep Reverse 10'000


Menu Terminal:

SCRV20
AC100000
SP10000
WA10000
PWC
RR100

17.3 Notes for Error 89


The error 89 shows a critical SMU error, which cannot be deleted by a command. The source of the error has first to be cleared and then the XENAX has to be restarted in order to delete the error. The description of the error is shown in WebMotion. If the error cannot be cleared or if the error occurs multiple times, please contact Jenny Science.

Click on the Button „ERROR 89“ and the window would be open.



The Fault description without WebMotion®

Open a terminal program and give in the command
„TESM“.




F-Number	Description	Note
210	host communication, external supervising, watchdog	Communication SMU to XENAX interrupted. Potentially, bad shielding of encoder cable
220	data consistency/checksum master/slave	Parameters were not uploaded correctly. Please try to download SMU parameters again.
232	firmware version not compatible	Firmware was not uploaded correctly. Please try to download SMU firmware again.
241	dynamic plausibility circuit encoder	Invalid state of one or more encoder signals. Check encoder cable, possible cable break. Restart XENAX®.
243	plausibility digital signal	Invalid voltage difference of one or more encoder signals. Check encoder cable, cable possibly broken
244	plausibility analogue signal	Unplugged encoder cable on XENAX®. Problems with the signal connecting. Cable possibly broken.
245	encoder cable disconnected	Encoder cable disconnected to XENAX®.
246	faulty input states	There is only one active Input from the safety. There must always be two Inputs activated for safety.
247	power active input test	Pin 9 is activated in XENAX®, this Input should not be used with the SMU
252	motor data failure	Motor data have not been forwarded to SMU. Potentially, there is bad shielding on the encoder cable

All other error codes are internal hardware failures. If error repeats multiple times, please contact Jenny Science.

17.4 Notes for Error 91


Error 91 shows not a critical SMU error. The source of the error, however, needs to be cleared. After that, the error can be normally deleted. The description of the error is shown in WebMotion.

Click on the Button „ERROR 91“ and the window would be open.



The Fault description without WebMotion®:

Open a terminal program and give in the command „TESM“.



F-Number	Description	Note
0	Motion blocked by unconfigured SMU	No safety function configured, motion blocked. As soon as a safety function is configured (see chapter 4.6 Functional Safety Parameterization in WebMotion®) the block is permanently removed. The blocking can also be temporarily removed until the next power cycle using the "DMBUS" command. CANopen direct command object 0x5000, value 0x5030
230	acceleration plausibility	Acceleration too high. Motion to hard mechanical limit
248	scale failure	For Jenny Science motors (LINAX/ELAX/ROTAX): Rise in temperature in the motor to fast or signal of measuring head too weak. Verify motion profile or for motors with glass measuring scale, please clean measuring scale. For motors of other manufacturers: Maybe DIP switch wrong. Dip Switch must be set to "No JSC motor" (refer to chapter 7 Configuration Motor Type Jenny Science / Motor customer specific).
249	overcurrent failure	Potential short circuit or ground fault in the motor cable / coils
250	overtemperature 3 phase power stage	Over 80°C measured by the temperature sensor in the output stage

17.5 Arbitrary Display on 7-Segment

After turning on the logic supply (24V), typically a "0" appears on the display. The green LED of the RJ45 connector lights up green when using active Ethernet connection.



If there is an arbitrary sign e.g. "8." or if the display is flickering, there are the following causes possible:



17.5.1 Defective adapter for logic supply

For the logic supply the adapter should deliver 24V DC and at least 300mA. Provides the adapter 24V DC for the logic as well as the power, 5A are required.

Measure logic supply (24VDC), change adapter if necessary.

17.5.2 Defective Firmware

If a wrong or corrupt firmware data was loaded or another cause:


Delete XENAX® with DIP switch firmware recorder and start boot loader:

DIP switch 2 ON

Logic supply ON, firmware recorder is being deleted, wait until „F“ on display, logic supply off,

DIP switch 2 OFF

Logic supply ON, display „F“ → boot loader active, Ethernet connection to PC/Laptop and load new firmware with WebMotion®.



17.5.3 GAL contact problems, only with hardware <=2.0

Remove and re-insert GAL.
It is also possible that there is a faulty capillary joint
on the GAL pedestal.



Note

This instruction manual contains copyright protected information. All rights are reserved. This document may not be in its entirety or partially copied, duplicated or translated without the prior consent of Jenny Science AG.

Jenny Science AG grants no guarantee on, or will be held responsible for, any incidents resulting from false information.

Information in this instruction manual is subject to change.

Jenny Science AG
Sandblatte 7a
CH-6026 Rain, Switzerland

Tel +41 (0) 41 455 44 55
Fax +41 (0) 41 455 44 50

www.jennyscience.ch
info@jennyscience.ch

© Copyright Jenny Science AG 2020